

MH20 and MH20i user's guide

www.renishaw.com

MH20 and MH20i user's guide

Documentation part number: H-1000-5195-06-F



MH20 and MH20i user's guide

www.renishaw.com

General information

© 2002 - 2022 Renishaw plc. All rights reserved.

 ORIGINAL LANGUAGE VERSION

This document may not be copied or reproduced in whole or in part, or transferred to any other media or language by any means, without the prior written permission of Renishaw.

Disclaimer

WHILE CONSIDERABLE EFFORT WAS MADE TO VERIFY THE ACCURACY OF THIS DOCUMENT AT PUBLICATION, ALL WARRANTIES, CONDITIONS, REPRESENTATIONS AND LIABILITY, HOWSOEVER ARISING, ARE EXCLUDED TO THE EXTENT PERMITTED BY LAW.

RENISHAW RESERVES THE RIGHT TO MAKE CHANGES TO THIS DOCUMENT AND TO THE EQUIPMENT, AND/OR SOFTWARE AND THE SPECIFICATION DESCRIBED HEREIN WITHOUT OBLIGATION TO PROVIDE NOTICE OF SUCH CHANGES.

Trade marks

RENISHAW®, the probe symbol and REVO® are registered trade marks of Renishaw plc.

Renishaw product names, designations and the mark 'apply innovation' are trade marks of Renishaw plc or its subsidiaries.

Other brand, product or company names are trade marks of their respective owners.

WEEE



The use of this symbol on Renishaw products and / or accompanying documentation indicates that the product should not be mixed with general household waste upon disposal. It is the responsibility of the end user to dispose of this product at a designated collection point for waste electrical and electronic equipment (WEEE) to enable reuse or recycling. Correct disposal of this product will help to save valuable resources and prevent potential negative effects on the environment. For more information, please contact your local waste disposal service or Renishaw distributor.

Warranty

Unless you and Renishaw have agreed and signed a separate written agreement, the equipment and/or software are sold subject to the Renishaw Standard Terms and Conditions supplied with such equipment and/or software, or available on request from your local Renishaw office.

Renishaw warrants its equipment and software for a limited period (as set out in the Standard Terms and Conditions), provided that they are installed and used exactly as defined in associated Renishaw documentation. You should consult these Standard Terms and Conditions to find out the full details of your warranty.

Equipment and/or software purchased by you from a third-party supplier is subject to separate terms and conditions supplied with such equipment and/or software. You should contact your third-party supplier for details.

MH20 and MH20i user's guide

www.renishaw.com

Care of equipment

Renishaw probes and associated systems are precision tools used for obtaining precise measurements and must therefore be treated with care.

Changes to Renishaw products

Renishaw reserves the right to improve, change or modify its hardware or software without incurring any obligations to make changes to Renishaw equipment previously sold.

Company registration details

Renishaw plc. Registered in England and Wales. Company no: 1106260. Registered office: New Mills, Wotton-under-Edge, Gloucestershire, GL12 8JR, UK.

Packaging

To aid end user recycling and disposal the materials used in the different components of the packaging are stated here:

Packaging component	Material	94/62/EC code	94/62/EC number
Outer box	Non-corrugated fibreboard	PAP	21
Packaging insert	Corrugated fibreboard	PAP	20
Bag	Low density Polyethylene	LDPE	4

MH20 and MH20i user's guide

www.renishaw.com

Product compliance

EU declaration of conformity

Contact Renishaw plc or visit www.renishaw.com/EUCMM for the full EU declaration.

UK declaration of conformity

Contact Renishaw plc or visit www.renishaw.com/UKCMM for the full UK declaration.

EMC conformity

This equipment must be installed and used in accordance with this installation guide. This product is intended for industrial use only and should not be used in a residential area or connected to a low voltage power supply network which supplies buildings used for residential purposes.

ICES-001 (Canada only)

This ISM device complies with Canadian ICES-001(A) / NMB-001(A).

Cet appareil ISM est conforme à la norme ICES-001(A) / NMB001(A) du Canada.

REACH regulation

Information required by Article 33(1) of Regulation (EC) No. 1907/2006 ("REACH") relating to products containing substances of very high concern (SVHCs) is available at:

www.renishaw.com/REACH

MH20 and MH20i user's guide

www.renishaw.com

China RoHS

Contact Renishaw plc or visit www.renishaw.com/ChinaRoHSCMM for the full China RoHS tabulation.



MH20 and MH20i user's guide

www.renishaw.com

Introduction

The MH20 and MH20i are manually operated probe heads that articulate to provide orientation of the probing axis. MH20 provides non-repeatable orientation, while MH20i permits repeatable indexing at 15° increments marked on the A and B axes. Both heads feature TP20 kinematic (magnetic) probe mounting, allowing stylus module changes without the need for re-qualification. A range of shanks is available to suit most CMM quills.

MH20 and MH20i user's guide

www.renishaw.com

Product description

MH20

The MH20 incorporates the TP20 kinematic mount with 2-axis adjustable swivel. The TP20 module is carried on the A-axis swivel and rotates through $\pm 93^\circ$ in the Z-plane. The B-axis rotates through $\pm 300^\circ$ in the X-Y plane. A thumbwheel locks the swivel in any position within the movement envelope of the head. After each adjustment qualification must take place. Module changing is possible without re-qualification.


MH20i

The MH20i incorporates the TP20 kinematic mount with 2-axis indexing. The TP20 module is carried on the A-axis swivel and rotates through 90° in the Z-plane. The B-axis rotates through $\pm 180^\circ$ in the X-Y plane.

The axes are unlocked by releasing the locking lever allowing rotation to each position. Positions are set at angular increments of 15° in each axis, providing a total of 168 positions.

When head orientation is locked, the probe is fully kinematically constrained in a highly repeatable spatial position.

This means that after initial qualification of the stylus tip, the probe may be moved to any of the qualified positions without the need for re-qualification during a gauging routine.



MH20 and MH20i

The red LED on the front of the head indicates probe status, and can be controlled by either the CMM or a Renishaw probe interface. Conventionally LED ON indicates probe seated (armed), and LED OFF indicates probe triggered.

Electrical connection is via a 5-pin DIN connector.

MH20 and MH20i user's guide

www.renishaw.com

MH20 specification

Measuring performance

See '[TP20 probe module](#)' for TP20 performance details.


Technical data

Range of articulation	A-axis 93° B-axis 300°
Dual axis lock	Single rotary thumbwheel
Mounting	MS/T range of shanks
Cable connection	5-pin DIN socket
Probe status indication	1 LED
Maximum load	EM2 - 94.5 mm (3.72 in) extension module
Operating temperature range	+10 °C to +40 °C (+50 °F to +104 °F)
Storage temperature range	-10 °C to +70 °C (+14 °F to +158 °F)
Probe mount	TP20 kinematic
Weight - without shank	100 g (3.53 oz)

MH20 and MH20i user's guide

www.renishaw.com


All dimensions are nominal



* See 'TP20 specifications'.

MH20 and MH20i user's guide

www.renishaw.com



Pin no.	Function
1	LED cathode
2	Ground
3	LED anode
4	Probe circuit
5	Probe circuit

MH20 and MH20i user's guide

www.renishaw.com

MH20i specification

Measuring performance

Positional repeatability (2σ)	
At stylus tip with TP20 standard force module and 10 mm (0.39 in) stylus length	1.5 μ m (0.00006 in)
At stylus tip with EM2 94.5 mm (3.72 in) extended module and stylus 10 mm (0.39 in) long	2.5 μ m (0.0001 in)


Technical data

Range of articulation	A-axis: 0° to 90° in 15° increments B-axis: \pm 180° in 15° increments
Dual axis lock	Single lock lever
Mounting	MS range of shanks
Cable connection	5-pin DIN socket
Probe status indication	1 LED
Maximum load	EM2 - 94.5 mm (3.72 in) extended module
Operating temperature range	+10 °C to +40 °C (+50 °F to +104 °F)
Storage temperature range	-10 °C to +70 °C (+14 °F to +158 °F)
Probe mount	TP20 kinematic
Weight - without shank	210 g (7.4 oz)

MH20 and MH20i user's guide

www.renishaw.com

All dimensions are nominal




* See 'TP20 specifications'

† From shank mounting face

MH20 and MH20i user's guide

www.renishaw.com



Electrical connection
5-pin DIN socket

Pin no.	Function
1	LED cathode
2	Ground
3	LED anode
4	Probe circuit
5	Probe circuit

MH20 and MH20i user's guide

www.renishaw.com

MH20 and MH20i installation

Mounting the shank to the probe head

- The MH20 and MH20i shanks are factory fitted and are selected by part no. when ordering (see '[Parts list](#)')
- MH20 shanks cannot be removed

MH20i

To mount a shank to an MH20i sold without a shank, please observe the following procedure:

- Hold the shank in the recess on the top face of the MH20i
- Rotate the shank until four screw holes are aligned
- Fix the shank in place using only M3 × 5 mm screws (supplied)
- Progressively tighten with the 2.5 mm A/F hex key (supplied)

Mounting the MH20 and MH20i head to the CMM

The head is normally attached to the CMM quill using a shank to suit the CMM.

For optimum shielding against EM phenomena it is recommended that the shank is grounded to the same electrical ground as the control system.

Custom designed mountings are available, subject to approval from Renishaw's Custom Products Department. Please contact your supplier or Renishaw for further information.

The head mounting must be rigid, as any movement during operation will introduce system measurement errors. If the head is replaced or repositioned in the quill, all head positions in current use must be re-qualified before making further measurements.

 **NOTE:** Remove plastic cap from kinematic mount prior to attaching a TP20 module. Keep in a safe place for future protection.

MH20 and MH20i user's guide

www.renishaw.com

MH20 operation


i **NOTE:** Ensure thumbwheel is unlocked one full turn before re-orientation. Failure to do this will result in excessive wear to the swivel anodised surfaces. Any wear to the swivel is cosmetic only and does not affect performance.

To change the orientation of the probe:

- Unlock the head by turning the thumbwheel anti-clockwise one full turn
- Grip the base of the swivel (avoid touching the stylus or stylus module) and manoeuvre the head to the desired position
- Lock the head in position by turning the thumbwheel clockwise until tight (do not use excessive force) - the probe is now ready for qualification
- Qualify the stylus tip whenever the head is re-orientated
- Qualify the stylus tip(s) according to the CMM supplier's instructions

Periodic re-qualification should be performed according to the following considerations:

- CMM supplier's recommendations, particularly in respect of temperature changes
- At the start of the working day or shift
- After an accidental collision
- After changing any measuring system component (except a pre-qualified TP20 module)
- If the initial state is unknown or uncertain



Replacement thumbwheel

If the thumbwheel is removed and then lost, a replacement can be ordered by quoting part no. A-4043-0120.

MH20 and MH20i user's guide

www.renishaw.com

MH20i operation

i **NOTE:** Ensure locking lever is in fully locked position before taking gauging points.


To change the orientation of the probe:

- Unlock the head by turning the lock lever to the fully anti-clockwise position
- Grip the body of the probe (avoid touching the stylus or stylus module) and rotate the B-axis until the desired angle indication on the scale is adjacent to the B-axis reference mark, increments are in 15°
- Rotate the A-axis until the desired angle indication on the scale is at the A-axis reference position, increments are in 15°
- Lock the head by turning the lock lever to the fully clockwise position
- Qualify the stylus tip(s) according to the CMM supplier's instructions
- Change the orientation of the probe to the next desired position and qualify the stylus tip(s)
- Repeat the qualification process for all desired orientations and stylus tips
- Commence gauging, ensuring that the correct qualification data is recalled for each head position
- Periodic re-qualification should be performed according to the following considerations:

CMM supplier's recommendations, particularly in respect of temperature changes.

- At the start of the working day or shift
- After an accidental collision
- After changing any measuring system component (except a pre-qualified TP20 module)
- If the initial state is unknown or uncertain

Locking lever operation



MH20 and MH20i user's guide

www.renishaw.com

TP20 probe module

The Renishaw TP20 probe module incorporates a kinematic coupling, which ensures highly repeatable stylus tip positioning.

The range of modules comprises 5-way versions with length or trigger force options and a 6-way version.

Probe modules fit directly onto the MH20 and MH20i kinematic mount. It is possible to change TP20 modules with different stylus configurations without re-qualification.

TP20 probe specification - standard force module described

Sense directions - 5-way	±X, ±Y, +Z
Unidirectional repeatability *	0.35 µm (0.000014 in) (2 sigma)
Module changing repeatability **	±1 µm, (0.000039 in)
XY pre-travel variation *	±0.8 µm, (0.000031 in)
Trigger force (non adjustable) ***	XY 0.08 N, 8 gf, 0.29 ozf Z 0.75 N, 76.5 gf, 2.7 ozf
TP20 module pull-off force	10 N, 1 kgf, 36 ozf max

Renishaw styli with M2 thread fit the TP20 probe module.

* Specified with standard force TP20 module with PS12R stylus and Renishaw PI 4-2 interface

** This can be achieved by taking care when changing modules (see 'Fitting the probe module with stylus on the MH20 or MH20i')

*** See 'Probing forces and overtravel limits' for LF, SF, MF and EF trigger force values

MH20 and MH20i user's guide

www.renishaw.com

The probe module

Each probe module houses the touch trigger mechanism that carries the stylus assembly. The module provides overtravel in the X, Y and Z axes. The M2 stylus mounting is compatible with Renishaw's comprehensive range of M2 styli.

Electrical contact pins automatically complete the probe circuit.

Trigger force and length option

Seven versions of the TP20 probe module can be used with the MH20 and MH20i, they can be identified by the end cap colour.

1	Standard force (SF) probe module	Black cap
2	Medium force (MF) probe module	Grey cap
3	Extended force (EF) probe module	Brown cap
4	Low force (LF) probe module	Green cap
5	Extended module (EM1) 69.5 mm (2.74 in) long	Black cap
6	Extended module (EM2) 94.5 mm (3.72 in) long	Black cap
7	TP20 6-way probe module	Blue cap

Medium and extended force modules are used to overcome the effects of false triggers, caused either by stylus length and mass, or vibration caused by machine acceleration forces.


The low force module permits the measurement of delicate objects.

The EM1 and EM2 extended modules allow access to otherwise inaccessible workpiece features. Both operate using standard force and offer better measuring performance than using long styli with MF, or EF modules.

The TP20 6-way senses in the +Z and -Z directions, allowing undercuts to be checked.

MH20 and MH20i user's guide

www.renishaw.com



Module	Stylus length - minimum	Stylus length - maximum	Overall reach
Low force (LF)	10 mm (0.39 in)	30 mm (1.18 in)	94 mm (3.70 in)
Standard force (SF)	10 mm (0.39 in)	50 mm (1.96 in)	114 mm (4.49 in)
Medium force (MF)	10 mm (0.39 in)	60 mm (2.36 in)	124 mm (4.88 in)
Extended force (EF)	10 mm (0.39 in)	60 mm (2.36 in)	124 mm (4.88 in)
6-way (6W)	10 mm (0.39 in)	30 mm (1.96 in)	98 mm (3.86 in)
EM1	10 mm (0.39 in)	50 mm (1.96 in)	143 mm (5.63 in)
EM2	10 mm (0.39 in)	50 mm (1.96 in)	168 mm (6.61 in)


MH20 and MH20i user's guide

www.renishaw.com

TP20 installation


Assembling the probe module and stylus

1. Select the probe module with the correct trigger force rating for the application (see 'TP20 module selector' and 'TP20 specifications').
2. Fit the stylus to the probe module, first hand tightening then using the S7 stylus tool (supplied) for final tightness. Renishaw GF styli require an S20 spanner. The recommended tightening torque is 0.05 Nm to 0.15 Nm (0.04 lb ft to 0.11 lb ft). Torque must not exceed 0.3 Nm (0.22 lb ft).



Fitting the probe module with stylus on the MH20 or MH20i

1. Examine all mating faces for cleanliness, where necessary clean the surfaces with the Renishaw CK200 cleaning kit. (supplied).
2. The TP20 module and kinematic mount are marked with three unique alignment marks. When offering the TP20 up to the probe head, ensure that similar marks are aligned with each other. Allow the TP20 body to engage under magnetic force.



MH20 and MH20i user's guide

www.renishaw.com

TP20 specifications

Probing forces and overtravel limits

Trigger force - nominal at stylus tip:

Probe module stylus length	LF 10 mm	SF 10 mm	MF 25 mm	EF 50 mm	EM1 10 mm	EM2 10 mm	TP20-6 way 10 mm
XY	0.055 N 5.5 gf 0.19 ozf	0.08 N 8 gf 0.28 ozf	0.1 N 10 gf 0.35 ozf	0.1 N 10 gf 0.35 ozf	0.08 N 8 gf 0.28 ozf	0.08 N 8 gf 0.28 ozf	0.14 N 14 gf 0.49 ozf
Z	0.65 N 65 gf 2.29 ozf	0.75 N 75 gf 2.64 ozf	1.9 N 190 gf 6.70 ozf	3.2 N 320 gf 11.29 ozf	0.75 N 75 gf 2.64 ozf	0.75 N 75 gf 2.64 ozf	1.6 N 160 gf 0.56 ozf

Overtravel force - maximum at stylus tip:

Probe module stylus length	LF 10 mm	SF 10 mm	MF 25mm	EF 50 mm	EM1 10 mm	EM2 10 mm	TP20-6 way 10 mm
XY	0.09 N 9 gf 0.31 ozf	0.2 N - 0.3 N 20 gf - 30 gf 0.7 ozf - 1.1 ozf	0.2 N - 0.4 N 20 gf - 40 gf 0.7 ozf - 1.4 ozf	0.2 N - 0.5 N 20 gf - 50 gf 0.7 ozf - 1.8 ozf	0.2 N - 0.3 N 20 gf - 30 gf 0.7 ozf - 1.1 ozf	0.2 N - 0.3 N 20 gf - 30 gf 0.7 ozf - 1.1 ozf	0.25 N 25 gf 0.88 ozf
(+)Z	1.15 N 115 gf 4.05 ozf	3.5 N 350 gf 12.35 ozf	7 N 700 gf 24.71 ozf	10 N 1000 gf 35.30 ozf	3.5 N 350 gf 12.35 ozf	3.5 N 350 gf 12.35 ozf	2.5 N 250 gf 8.83 ozf
-Z	- - -	- - -	- - -	- - -	- - -	- - -	9 N 900 gf 31.8 ozf

MH20 and MH20i user's guide

www.renishaw.com

Overtravel displacement:

Probe module stylus length	LF 10 mm	SF 10 mm	MF 25 mm	EF 50 mm	EM1 10 mm	EM2 10 mm	TP20-6 way 10 mm
XY *	±14°	±14°	±14°	±14°	±14°	±14°	±14°
(+)Z	3.1 mm (0.12 in)	4 mm (0.16 in)	3.7 mm (0.14 in)	2.4 mm (0.09 in)	4 mm (0.16 in)	4 mm (0.16 in)	4.5 mm (0.18 in)
-Z	- -	- -	- -	- -	- -	- -	1.5 mm (0.06 in)

* The module may become detached if this value is exceeded.

Length:

Probe module stylus length	LF 10 mm	SF 10 mm	MF 25 mm	EF 50 mm	EM1 10 mm	EM2 10 mm	TP20-6 way 10 mm
Length *	19.5 mm (0.77 in)	19.5 mm (0.77 in)	19.5 mm (0.77 in)	19.5 mm (0.77 in)	69.5 mm (2.74 in)	94.5 mm (3.72 in)	24.5 mm (0.96 in)

* See '[MH20 dimensions](#)' and '[MH20i dimensions](#)'

Module changing	Changed manually probe repeatability is ±1 µm
-----------------	---

MH20 and MH20i user's guide

www.renishaw.com

Fault finding

MH20 and MH20i

Poor measuring performance:

Possible cause	Remedy
Loose mounting.	Ensure shank mounting screws are tight and mounting to CMM is secure.
Problem with TP20 probe module (see 'TP20 installation').	Diagnosis of the probe unit should be carried out with axes correctly locked and without head adjustment between probe points.
Problem with swivelling / indexing unit.	Diagnosis of indexing unit should only be carried out following confirmation of satisfactory probe performance.

No probe signal and / or no probe status LED:

Possible cause	Remedy
Cable faulty / not connected.	Check continuity of cabling from head to interface / machine control.
Probe interface faulty / not connected.	Ensure correct connection of interface/machine control.

Poor repeatability (MH20i only):

Possible cause	Remedy
Axes lock procedure incorrect.	Ensure lock lever is fully rotated to lock position.
Axes unlock procedure incorrect.	Ensure lock lever is fully rotated to unlock position during indexing.
Forces imparted onto head during lock-up.	Unlock and re-lock holding lock lever only.
Attempted lock-up in incorrect un-qualified position.	Unlock, reposition correctly and re-lock.

Axes 'rattling' during indexing (MH20i only):

Possible cause	Remedy
Incorrect unlock procedure.	Ensure lock lever is fully rotated to unlock position.
Incorrect indexing procedure.	Index each axis separately.

 **NOTE:** The MH20 and MH20i are not user serviceable and should be returned to Renishaw if suspected faulty.

MH20 and MH20i user's guide

www.renishaw.com

TP20 module

Poor measuring performance:

Possible cause	Remedy
Stylus configuration too long or not rigid.	Use shorter stiffer stylus configuration.
Poor stylus assembly.	Ensure stylus joints are kept to a minimum and that all joints are clean and secure.
Contamination / damage of stylus ball.	Inspect for damage, clean thoroughly with solvent.
Trigger force too high.	Use lower force module.

Unwanted triggering during probe or CMM movement:

Possible cause	Remedy
Trigger force too low / stylus configuration too heavy.	Use higher force module / reduce mass of stylus configuration.

Probe fails to rearm after trigger:

Possible cause	Remedy
Trigger force too low / stylus configuration too heavy.	Use higher force module / reduce mass of stylus configuration.
Probe reseal failure.	Re-trigger probe. If problem persists please return to Renishaw for service.

Loss of measuring accuracy:

Possible cause	Remedy
Mounting not secure.	Check that the MH20i is correctly mounted on the shank and that the screws are secure. Check clamping mechanism in CMM quill is secure for MH20 and MH20i.
MH20 / MH20i not fully locked.	Ensure that the thumbwheel / lock lever is turned fully clockwise.
Force imparted to probe module after locking.	Re-qualify the probe.
MH20 / MH20i worn or damaged.	Use only with the specified probe and extension combinations.
Faulty probe module.	Check by substitution or return to Renishaw or your supplier.

MH20 and MH20i user's guide

www.renishaw.com

Maintenance

Renishaw probes are intended for use in a protected metrology environment and therefore accumulation of dust or contamination should not occur.

In common with all precision measuring equipment, regular inspection and cleaning is recommended to ensure continued high performance.

Maintenance of the head is limited to wiping the outer surfaces and axes scale labels with a clean dry cloth or proprietary cleaning material.

Maintenance of the TP20 probe is restricted to the periodic cleaning of the kinematic couplings on the probe head and the probe module. To aid cleaning of these couplings, the MH20 and MH20i are supplied with a Renishaw CK200 cleaning kit. Do not use any other cleaning method.

When operating the TP20 probe in environments subjected to air-borne contamination, the user should determine the frequency of cleaning required.

MH20 and MH20i user's guide

www.renishaw.com

Parts list

TP20 probe modules

The MH20 and MH20i can be ordered with either LOW, STD, MED, or EXT force modules (see 'Head and shank combinations - MH20' and 'Head and shank combinations - MH20i' for details). If additional modules are required please refer to the table below for part numbers:

TP20 modules

Description	Part number
LOW	A-1371-0392
STD	A-1371-0270
MED	A-1371-0271
EXT	A-1371-0272
EM1	A-1371-0430
EM2	A-1371-0431
TP20 6-way	A-1371-0419

Probe tools

Description	Part number
S7 stylus tool kit (supplied)	A-5000-7835
S20 stylus tool (not supplied)	A-5003-2300
CK200 cleaning kit (supplied)	A-1085-0016

MH20 and MH20i user's guide

www.renishaw.com

Head and shank combinations - MH20

Description	Part number
MH20 + MS1/T shank	A-4043-xx01 *
MH20 + MS2/T shank	A-4043-xx02 *
MH20 + MS3/T shank	A-4043-xx03 *
MH20 + MS5/T shank	A-4043-xx05 *
MH20 + MS7/T shank	A-4043-xx07 *
MH20 + MS9/T shank	A-4043-xx09 *
MH20 + MS11/T shank	A-4043-xx11 *
MH20 + MS15/T shank	A-4043-xx15 *
MH20 + MS18/T shank	A-4043-xx18 *

* For LOW force module insert 00

* For STD force module insert 01

* For MED force module insert 02

* For EXT force module insert 03

e.g. For MH20 with STD force module and MS9/T shank the part number is: A-4043-0109.



NOTE: For more information on the Renishaw shank range please refer to H-1000-5050.

MH20 and MH20i user's guide

www.renishaw.com

Head and shank combinations - MH20i

Description	Part number
MH20i + MS1 shank	A-4099-xx01 *
MH20i + MS2 shank	A-4099-xx02 *
MH20i + MS3 shank	A-4099-xx03 *
MH20i + MS4 shank	A-4099-xx04 *
MH20i + MS5 shank	A-4099-xx05 *
MH20i + MS6 shank	A-4099-xx06 *
MH20i + MS7 shank	A-4099-xx07 *
MH20i + MS9 shank	A-4099-xx09 *
MH20i + MS10 shank	A-4099-xx10 *
MH20i + MS12 shank	A-4099-xx12 *
MH20i + MS13 shank	A-4099-xx13 *
MH20i + MS14 shank	A-4099-xx15 *
MH20i + MS15 shank	A-4099-xx15 *
MH20i + MS17 shank	A-4099-xx17 *
D shank	A-4099-xx18 *

* For LOW force module insert 00

* For STD force module insert 01

* For MED force module insert 02

* For EXT force module insert 03

e.g. For MH20i with MED force module and MS7 shank the part number is: A-4099-0207.



NOTE: For more information on the Renishaw shank range please refer to H-1000-5050.

Renishaw plc
New Mills, Wotton-under-Edge
Gloucestershire, GL12 8JR
United Kingdom

T +44 (0)1453 524524
F +44 (0)1453 524901
www.renishaw.com/cmmsupport



**For worldwide contact details,
please visit our main website at
www.renishaw.com/contact**