


# ATOM DX™ and RTLF linear encoder system



[www.renishaw.com/atomdxdownloads](http://www.renishaw.com/atomdxdownloads)

 #renishaw

This page is intentionally left blank.

## Contents

Legal notices .....	5
Storage and handling .....	10
ATOM DX system installation overview .....	12
RTLF tape scale installation drawing .....	13
RTLF application methods .....	14
Equipment required to ledge or dowel mount the RTLF .....	15
RTLF scale application (ledge or dowel mounting) .....	16
Equipment required for mounting the RTLF with a scale applicator .....	18
RTLF scale application (any scale length) .....	19
Fitting the scale datum clamp .....	21
Fitting the scale end covers .....	21
RTLF reference mark deselection .....	22
System connection: Top exit readhead .....	23
Readhead mounting and alignment: Methods .....	25
ATOM DX calibration overview .....	31
System calibration .....	32
Restoring factory defaults .....	33
Switching Automatic Gain Control (AGC) on or off .....	33
Readhead LED diagnostics .....	34
Troubleshooting .....	35
ATOM DX cabled readhead dimensions .....	38
ATOM DX top exit readhead dimensions .....	39
Bracket dimensions .....	40

Output signals .....	41
Speed .....	42
Electrical connections .....	44
Output specifications .....	46
General specifications .....	47
RTLF scale specifications .....	48

## Legal notices

### Patents

Features of Renishaw's ATOM DX™ encoder systems and similar products are the subjects of one or more of the following patents and patent applications:

EP1946048	JP5017275	US7624513	EP1957943	US7839296
CN105008865	EP3564628	EP2936073	IN428552	JP6563813
KR2128135	US9952068	US10768026	CN106104216	EP3052898
IN429478	JP7153997	US10281301	CN105814408	EP3052897
IN455785	JP7032045	US10823587	CN106030251	EP3052895
JP6811610	EP3052900	IN399411	JP7083228	US11543270
US8466943				

### Terms and conditions and warranty

Unless you and Renishaw have agreed and signed a separate written agreement, the equipment and/or software are sold subject to the Renishaw Standard Terms and Conditions supplied with such equipment and/or software, or available on request from your local Renishaw office.

Renishaw warrants its equipment and software for a limited period (as set out in the Standard Terms and Conditions), provided that they are installed and used exactly as defined in associated Renishaw documentation. You should consult these Standard Terms and Conditions to find out the full details of your warranty.

Equipment and/or software purchased by you from a third-party supplier is subject to separate terms and conditions supplied with such equipment and/or software. You should contact your third-party supplier for details.

### Declaration of Conformity

Renishaw plc hereby declares that the ATOM encoder system is in compliance with the essential requirements and other relevant provisions of:



The full text of the declaration of conformity is available at: [www.renishaw.com/productcompliance](http://www.renishaw.com/productcompliance).

### Compliance

#### Federal Code Of Regulation (CFR) FCC Part 15 – RADIO FREQUENCY DEVICES

##### 47 CFR Section 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

##### 47 CFR Section 15.21

The user is cautioned that any changes or modifications not expressly approved by Renishaw plc or authorised representative could void the user's authority to operate the equipment.

##### 47 CFR Section 15.105

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## 47 CFR Section 15.27

This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to ensure compliance.

## Supplier's Declaration of Conformity

## 47 CFR § 2.1077 Compliance Information

Unique Identifier: ATOM DX

### Responsible Party - U.S. Contact Information

Renishaw Inc.  
1001 Wesemann Drive  
West Dundee  
Illinois  
IL 60118  
United States  
Telephone number: +1 847 286 9953  
Email: [usa@renishaw.com](mailto:usa@renishaw.com)

### ICES-003 – Information Technology Equipment (including Digital Apparatus)

This ISM device complies with Canadian ICES-003(A).

Cet appareil ISM est conforme à la norme ICES-003(A).

## Intended use

The ATOM DX encoder system is designed to measure position and provide that information to a drive or controller in applications requiring motion control. It must be installed, operated, and maintained as specified in Renishaw documentation and in accordance with the Standard Terms and Conditions of the Warranty and all other relevant legal requirements.

## Further information

Further information relating to the ATOM DX encoder range can be found in the *ATOM DX™ miniature encoder system* data sheet (Renishaw part no. L-9517-9736), *Advanced Diagnostic Tool ADTi-100* data sheet (Renishaw part no. L-9517-9699), *Advanced Diagnostic Tool ADTi-100 and ADT View software* quick-start guide (Renishaw part no. M-6195-9321), and the *Advanced Diagnostic Tool ADTi-100 and ADT View software* user guide (Renishaw part no. M-6195-9413). These can be downloaded from our website at [www.renishaw.com/atomdxdownloads](http://www.renishaw.com/atomdxdownloads) and are also available from your local representative.

## Packaging

The packaging of our products contains the following materials and can be recycled.

Packing component	Material	ISO 11469	Recycling guidance
Outer box	Cardboard	Not applicable	Recyclable
	Polypropylene	PP	Recyclable
Inserts	Low density polyethylene foam	LDPE	Recyclable
	Cardboard	Not applicable	Recyclable
Bags	High density polyethylene bag	HDPE	Recyclable
	Metalised polyethylene	PE	Recyclable

## REACH regulation

Information required by Article 33(1) of Regulation (EC) No. 1907/2006 ("REACH") relating to products containing substances of very high concern (SVHCs) is available at [www.renishaw.com/REACH](http://www.renishaw.com/REACH).

## Disposal of waste electrical and electronic equipment



The use of this symbol on Renishaw products and/or accompanying documentation indicates that the product should not be mixed with general household waste upon disposal. It is the responsibility of the end user to dispose of this product at a designated collection point for waste electrical and electronic equipment (WEEE) to enable reuse or recycling. Correct disposal of this product will help to save valuable resources and prevent potential negative effects on the environment. For more information, contact your local waste disposal service or Renishaw distributor.

# ATOM DX software notices

## Third party licences

The ATOM DX product includes embedded software (firmware) to which the following notices apply:

Copyright © 2009 - 2013 ARM LIMITED

All rights reserved.

This Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of ARM nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL COPYRIGHT HOLDERS AND CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright © NXP Semiconductors, 2012

All rights reserved.

Software that is described herein is for illustrative purposes only which provides customers with programming information regarding the LPC products.

This software is supplied "AS IS" without any warranties of any kind, and NXP Semiconductors and its licensor disclaim any and all warranties, express or implied, including all implied warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights.

- NXP Semiconductors assumes no responsibility or liability for the use of the software, conveys no license or rights under any patent, copyright, mask work right, or any other intellectual property rights in or to any products.
- NXP Semiconductors reserves the right to make changes in the software without notification.
- NXP Semiconductors also makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Permission to use, copy, modify, and distribute this software and its documentation is hereby granted, under NXP Semiconductors' and its licensor's relevant copyrights in the software, without fee, provided that it is used in conjunction with NXP Semiconductors microcontrollers. This copyright, permission, and disclaimer notice must appear in all copies of this code.

## US government notice


### NOTICE TO UNITED STATES GOVERNMENT CONTRACT AND PRIME CONTRACT CUSTOMERS

This software is commercial computer software that has been developed by Renishaw exclusively at private expense. Notwithstanding any other lease or licence agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government and/or its prime contractors regarding its use, reproduction and disclosure are as set forth in the terms of the contract or subcontract between Renishaw and the United States Government, civilian federal agency or prime contractor respectively. Please consult the applicable contract or subcontract and the software licence incorporated therein, if applicable, to determine your exact rights regarding use, reproduction and/or disclosure.


## Renishaw End User Licence Agreement (EULA)

Renishaw software is licensed in accordance with the Renishaw licence at [www.renishaw.com/  
legal/softwareterms](http://www.renishaw.com/legal/softwareterms).

## Storage and handling





### Minimum bend radius



**NOTE:** During storage, ensure that the self-adhesive tape is on the outside of the bend.


## System






## Temperature

Storage	
System	-20 °C to +70 °C




Operating	
System	0 °C to +70 °C



## Humidity

95% relative humidity (non-condensing) to IEC 60068-2-78




# ATOM DX system installation overview

This section gives an overview of the steps involved in installing, setting-up and calibrating an ATOM DX encoder system. More detailed information is contained within the rest of the document.


For information on designing the readhead and scale into the system refer to the detailed installation drawings and 3D models at [www.renishaw.com/atomdxdownloads](http://www.renishaw.com/atomdxdownloads) or contact your local Renishaw representative. For information on the ATOM DX product range refer to the *ATOM DX™ miniature encoder system* data sheet (Renishaw part no. L-9517-9736).

**IMPORTANT:** Prior to installing the readhead and linear scale, the installation drawing should be reviewed to ensure correct orientation of the readhead relative to the scale (see page 13).



## RTLF tape scale installation drawing

Dimensions and tolerances in mm



Overall length (with optional end covers) = Measuring length + 50 mm

Scale length (with optional end covers) = Measuring length + 13 mm

Scale length (without end covers) = Measuring length + 6 mm


**NOTE:** ATOM DX cabled readhead variant shown.<sup>1</sup>

<sup>1</sup> For readhead dimensions see pages 38 and 39.


## RTLF application methods

The RTLF scale application method depends upon the scale length and the bracket type being used.


### Ledge or dowel mounting the scale (RTLF scale lengths < 500 mm only)



Ledge or dowel mount  
(see page 15)




Datum edge of the readhead located against a ledge on the bracket to control yaw. For use with the 'L' mounting bracket A-9402-0037 or a customer-designed bracket.




Top mount applicator A-9402-0028  
(see page 18)


### Using an adjustable bracket



Datum edge of the readhead mounted against the machine axis. For use with the side mounting bracket A-9401-0103 or a customer-designed bracket.




Side-mounted applicator A-9402-0034.  
Only for use with 'L' mounting bracket  
A-9402-0037 (see page 18)




Slim applicator A-9402-0060  
(see page 18)

### Mounting the scale with a scale applicator (any RTLF scale length)

#### Using a fixed mounting



Readhead mounting is integral to the machine and does not allow rideheight adjustment.



Top mount applicator A-9402-0028  
(see page 18)

Install the datum clamp and scale end covers (see page 21)

Deselect the unused reference marks (see page 22)

## Equipment required to ledge or dowel mount the RTLF

### Suitable for:

RTLF tape scale lengths < 500 mm long.

### Required parts:


- An appropriate length of RTLF tape scale (see '[RTLF tape scale installation drawing](#)' on page [13](#))
- Appropriate cleaning solvents (see '[Storage and handling](#)' on page [10](#))
- Datum clamp (A-9585-0028)
- Loctite® 435™ (P-AD03-0012)

### Optional parts:


- Renishaw scale wipes (A-9523-4040)
- Loctite 435 dispensing tip (P-TL50-0209)
- End cover kit (A-9585-0035)
- Reference mark deselection stickers (A-9402-0049 for a sheet of 20)
- Lint-free cloth

## RTLF scale application (ledge or dowel mounting)


1. Thoroughly clean and degrease the substrate using recommended solvents (see 'Storage and handling' on page 10). Allow the substrate to dry before applying the scale.



2. Remove the backing paper from the scale.




3. Locate the scale against dowels or a ledge and rotate down onto the substrate.<sup>1</sup>



<sup>1</sup> If the dowels or the ledge are permanent, their maximum height above the substrate should not exceed 0.6 mm.

4. Clean the scale using Renishaw scale wipes or a clean, dry, lint-free cloth.



5. Fit the datum clamp and the end covers (see '[Fitting the scale datum clamp](#)' and '[Fitting the scale end covers](#)' on page 21) and, if needed, deselect the reference marks that are not required (see '[RTLF reference mark deselection](#)' on page 22).
6. Remove the temporary dowels (if fitted).

# Equipment required for mounting the RTLF with a scale applicator

## Suitable for:

Any length of RTLF tape scale.

### Required parts:

- An appropriate length of RTLF tape scale (see 'RTLF tape scale installation drawing' on page 13)
- Appropriate cleaning solvents (see 'Storage and handling' on page 10)
- Datum clamp (A-9585-0028)
- Loctite® 435™ (P-AD03-0012)
- Readhead mounting bracket (see table below)
- Appropriate scale applicator (see table below)
- 2 × applicator mounting screws
- 2 M2 × 6 screws, top mount applicator only


### Optional parts:

- Renishaw scale wipes (A-9523-4040)
- Loctite 435 dispensing tip (P-TL50-0209)
- End cover kit (A-9585-0035)
- Reference mark deselection stickers (A-9402-0049 for a sheet of 20)
- Lint-free cloth

## Readhead mounting bracket and scale applicator:

The correct version of the scale applicator that should be used depends upon the design of the readhead mounting bracket being used. For more information on designing your bracket, contact your local Renishaw representative.

Mounting	In place of the readhead bracket	In place of the readhead bracket	In place of the readhead
Applicable bracket	Side mounting bracket (A-9401-0103) or a customer-designed bracket	'L' mounting bracket (A-9402-0037) or a customer-designed bracket	'L' mounting bracket (A-9402-0037) or a customer-designed bracket



## RTLF scale application (any scale length)



1. Allow the RTLF scale to acclimatise to the installation environment prior to installation.
2. Mark out the start position for the scale on the axis substrate.
3. Thoroughly clean and degrease the substrate using recommended solvents (see 'Storage and handling' on page 10). Allow the substrate to dry before applying the scale.
4. Mount the chosen scale applicator (see 'Readhead mounting bracket and scale applicator:' on page 18).
5. Move axis to the start of travel leaving enough room for the scale to be inserted through the applicator, as shown below.
6. Check the correct scale orientation (see 'RTLF tape scale installation drawing' on page 13).

### 7. Slim or side mount applicators:


- Begin to peel off the backing paper from the end of the scale and insert the scale into the applicator up to the start position.
- Ensure the backing paper feeds out of the back of the applicator around the splitter screw as shown on the following page.

### Top mount applicator:

- Cut the backing paper approximately 30 mm from the end of the scale.
- Leaving the end piece adhering to the scale, begin to peel off the remaining backing paper.
- Insert the scale into the applicator up to the start position.
- Ensure the backing paper feeds out of the back of the applicator



8. Apply firm finger pressure via a clean, dry, lint-free cloth to ensure the scale end adheres well to the substrate.
9. Slowly and smoothly move the applicator through the entire length of travel, ensuring the backing paper is pulled manually from the scale and does not catch under the applicator.



10. Remove the applicator and, if necessary, adhere the remaining scale manually.

**NOTE:** When using the top mount applicator ensure the backing paper left at the start of the axis is removed.

11. Apply firm finger pressure via a clean, dry, lint-free cloth along the length of the scale after application to ensure complete adhesion.

12. Remove the applicator and, if necessary, adhere the remaining scale manually.

**NOTE:** Slim and side mount applicators only: Fit the readhead mounting bracket after removal of scale applicator.

13. Clean the scale using Renishaw scale wipes or a clean, dry, lint-free cloth.


14. Fit the datum clamp and the end covers (see '[Fitting the scale datum clamp](#)' and '[Fitting the scale end covers](#)' on page 21) and, if needed, deselect the reference marks that are not required (see '[RTLF reference mark deselection](#)' on page 22).

## Fitting the scale datum clamp

The datum clamp fixes the RTLF scale rigidly to the substrate at the location chosen.

**CAUTION:** The metrology of the system may be compromised if the datum clamp is not used. It can be positioned anywhere along the axis depending upon the customers' requirements.

1. Remove the backing paper from the datum clamp. Place the datum clamp with cut-out against the scale at the chosen location.
2. Place a small amount of adhesive (Loctite 435) in the cut-out on the datum clamp, ensuring none of the adhesive wicks onto the scale surface.




## Fitting the scale end covers


The end cover kit is designed to be used with RTLF scale to provide protection for exposed scale ends.

**NOTE:** End covers are optional and can be fitted before or after readhead installation.

1. Remove the backing paper from the adhesive tape on the back of the end cover.



2. Align the markers on the edges of the end cover with the end of the scale and place the end cover over the scale.




**NOTE:** There will be a gap between the end of the scale and the adhesive tape on the end cover.


## RTLF reference mark deselection

RTLF tape scale > 100 mm in length has reference marks every 50 mm. Stickers can be used to deselect all of the unused reference marks. The stickers are aligned on the backing paper with a 50 mm spacing so two can be selected at once for deselecting two reference marks.

1. Ensure the scale is free from dirt and grease by cleaning with a Renishaw scale wipe or one of the recommended solvents (see '[Storage and handling](#)' on page 10).
2. Place the transparent applicator film over the reference mark deselecter stickers and rub firmly until the sticker adheres to the applicator film. Two stickers can be selected at once.
3. Remove the applicator film, complete with the stickers, from the backing paper.



4. Align the stickers on the scale over the reference marks that are not required, as shown in the diagram below, then rub firmly on the applicator film until the stickers adhere to the scale. Care should be taken to ensure the stickers fully cover the reference mark and do not obscure any of the incremental track.



5. Remove the applicator film.

## System connection: Top exit readhead

A range of cables for top exit readheads are available:

15-way D-type connector	
Cable length (m)	Part number
0.5	A-9414-1223
1.0	A-9414-1225
1.5	A-9414-1226
3.0	A-9414-1228

10-way JST	
Cable length (m)	Part number
0.5	A-9414-1233
1.0	A-9414-1235
1.5	A-9414-1236
3.0	A-9414-1238

- Provide appropriate strain relief at the readhead. The Renishaw top exit cables are fitted with a P-clip to ensure appropriate cable strain relief.
- When using Renishaw's top exit cables ensure that the P-clip is mounted within a 50 mm radius of the readhead cable exit.
- The minimum static bend radius of cores is 3 mm.
- For challenging dynamic applications consider additional strain relief of the cores.
- Ensure there is no relative movement between the readhead and the P-clip.
- The maximum number of insertions for the readhead connector is 20 cycles. Care should be taken when removing the connector to avoid pulling out cores from the cable connector.


## Shielding

For optimum performance:


- Ensure 100% shielding.
- Ground the mounting brackets.
- Ensure continuity between the readhead body and cable shield. For Renishaw top exit cables the P-clip provides electrical connection to the cable shield.
- Maximise the distance between the encoder and motor cables.

## Top exit readhead (with readhead cable inserted)


Dimensions and tolerances in mm



Detail A: Connector (readhead end) and P-clip



Detail B: P-clip dimensions



## Readhead mounting and alignment: Methods


There is a range of tools available to assist with readhead installation depending upon the system design and these are detailed below. For more details on designing the mounting bracket and selecting the appropriate mounting tools contact your local Renishaw representative.

Ensure that the scale, readhead optical window and mounting face are clean and free from obstruction.

**CAUTION:** Do not saturate the readhead window with cleaning solvent as this may cause contamination on the inside of the readhead window which then cannot be cleaned.

**IMPORTANT:** Whichever method is used to mount the readhead, care should be taken to ensure the scale surface is not damaged during this operation, particularly when metal-to-metal contact is necessary.


**NOTE:** Cabled readheads are shown in the following pages, but the same readhead mounting and alignment methods are applicable for top exit readheads.



## Shim kit (A-9401-0050)

This method is intended for applications where the rideheight of the readhead cannot be adjusted.

The system should be designed to achieve a nominal 2.3 mm ( $\pm 0.2$  mm) from the readhead mounting surface to the top of the scale.




Shims of a known thickness are inserted between the mounting face of the readhead and the bracket to give the correct rideheight of 2.5 mm ( $\pm 0.2$  mm).

### Required parts

- Dial test indicator (DTI) or similar
- 2 M2 x 6 screws
- ATOM readhead shim kit (A-9401-0050) consisting of:

Part number	Thickness (µm)	Quantity in pack
A-9401-0041	20	10
A-9401-0042	40	10
A-9401-0043	60	10
A-9401-0044	80	10
A-9401-0045	100	20
A-9401-0046	200	20
A-9401-0047	300	10



- Hex key
- ATOM DX readhead

### Optional parts


- DTI adaptor (A-9401-0105)

1. Using a dial test indicator or similar, measure the distance from the readhead mounting surface to the scale surface.

Care must be taken to ensure the scale surface is not scratched. Renishaw offer a DTI adapter that can be used to assist with this process.

- Insert the DTI into the adapter and zero it on a flat surface.
- Position or fix the indicator/adapter in place of the readhead and measure the distance to the scale surface.

Contact your local Renishaw representative for details of the DTI and adaptor.




2. Subtract the distance measured from the nominal rideheight of 2.5 mm to calculate the required shim thickness. For example if the distance measured is 2.37 mm the required shim thickness is 130 µm.

3. Select the smallest number of shims that gets within 10 µm of the difference. For distances less than 100 µm a single shim should be used; for distances greater than 100 µm select one thick ( $\geq 100$  µm) and one thin ( $< 100$  µm) shim.

In the above example of a required shim thickness of 130 µm this could either be: 1 x 100 µm shim and 1 x 40 µm shim or 1 x 100 µm shim and 1 x 20 µm shim.


4. Place the chosen shim(s) between the readhead and the bracket.
5. Fix the readhead to the bracket using 2 M2 x 6 screws in diagonally opposite fixing holes, ensuring the readhead is tightened down evenly and parallel to the bracket face.



6. Connect the readhead to the receiving electronics and power-up.
7. Check the readhead set-up LED is flashing green along the full axis of travel.
8. Proceed with 'System calibration' on page 32.

## Dummy head (A-9401-0072)

The reusable dummy head has the same mounting holes as the ATOM DX readhead with a longer 'nose' that is machined to the optimum rideheight (2.5 mm  $\pm 0.02$  mm).




It is mounted in place of the readhead directly onto the bracket. The bracket should have location pins or a shoulder to control readhead yaw. Contact your local Renishaw representative for more information on bracket design.


### Required parts

- Dummy head (A-9401-0072)
- 2 M2 x 6 screws
- Side mount bracket (A-9401-0103), 'L' mounting bracket (A-9402-0037), or customer designed bracket<sup>1</sup>
- 2 bracket mounting screws
- Hex key
- ATOM DX readhead

1. Mount the dummy head onto the bracket using 2 M2 x 6 screws.





Side mount bracket



'L' mounting bracket



2. Loosely mount the readhead bracket onto the axis.





3. Adjust the height of the bracket until the 'nose' of the dummy head just touches the scale.

<sup>1</sup> For more information on bracket design contact your local Renishaw representative.

4. Tighten the bracket fixing screws whilst ensuring good contact between the 'nose' of the dummy head and the surface of the scale.



5. Remove the dummy head.
6. Install the ATOM DX readhead in place of the dummy head using 2 M2 x 6 screws in diagonally opposite fixing holes. Ensure the readhead is pushed back against the shoulder of the bracket or the mounting face.



7. Connect the readhead to the receiving electronics and power-up.
8. Check the readhead set-up LED is flashing green along the full axis of travel.
9. Proceed with 'System calibration' on page 32.


## Accurate bracket and feeler gauge

For applications where the readhead mounting bracket allows adjustment of rideheight with a bracket thickness of  $2 \pm 0.02$  mm.

### Required parts

- 'L' mounting bracket (A-9402-0037) or a customer designed bracket with a thickness of  $2 \pm 0.02$  mm <sup>1</sup>
- 2 bracket mounting screws
- 0.5 mm feeler gauge
- 2 M2 x 6 screws
- Hex key
- ATOM DX readhead

1. Mount the readhead onto the bracket.
2. Loosely mount the readhead bracket onto the axis.
3. Place the feeler gauge between the readhead bracket and the scale.



4. Tighten the bracket fixing screws whilst ensuring good contact between the bracket, shim and surface of the scale.
5. Connect the readhead to the receiving electronics and power-up.
6. Check the readhead set-up LED is flashing green along the full axis of travel.
7. Proceed with '[System calibration](#)' on page 32.

<sup>1</sup> For more information on bracket design contact your local Renishaw representative.

## ATOM DX calibration overview

This section is an overview of the calibration procedure for an ATOM DX encoder system. More detailed information on calibrating the readhead is contained on page 32 of this installation guide. The optional Advanced Diagnostic Tool ADT-100<sup>1</sup> (A-6195-0100) and ADT View software<sup>2</sup> can be used to aid installation and calibration.

### Calibrate system

Ensure the readhead set-up LED is flashing green along the full axis of travel before system calibration. See page 25 to page 30 for more information on readhead mounting and alignment.

 Cycle the power to the readhead to initiate the calibration routine. The LED will single flash blue.

 Move the readhead along the scale at slow speed (< 100 mm/s), without passing a reference mark, until the LED starts double flashing blue.

#### No reference mark

If a reference mark is not being used, the calibration routine should now be exited by cycling the power. The LED will stop flashing.

#### Reference mark

 Move the readhead back and forth over the chosen reference mark until the LED stops flashing.

 The system is now calibrated and ready for use. Calibration values, Automatic Gain Control (AGC) and Automatic Offset Control (AOC) status are stored in readhead non-volatile memory at power down.

**NOTE:** If the calibration routine fails (the readhead LED remains single flashing blue), restore the readhead factory defaults (see 'Restoring factory defaults' on page 33) and repeat the installation and calibration routine.

<sup>1</sup> For more details refer to the *Advanced Diagnostic Tool ADT-100 and ADT View software User guide* (Renishaw part no. M-6195-9413) and *Advanced Diagnostic Tool ADT-100 and ADT View software Quick-start guide* (Renishaw part no. M-6195-9321).

<sup>2</sup> The software can be downloaded for free from [www.renishaw.com/adt](http://www.renishaw.com/adt).

# System calibration

**NOTE:** The functions described below can also be carried out by using the optional ADTi-100 and ADT View software. See [www.renishaw.com/adt](http://www.renishaw.com/adt) for more information.

## Before system calibration:

1. Clean the scale and the readhead's optical window.
2. If reinstalling, restore the readhead's factory defaults (see '[Restoring factory defaults](#)' on page [33](#)).
3. Maximise the signal strength along the full axis of travel (the readhead set-up LED is flashing green).

**NOTE:** During calibration the speed should not exceed 100 mm/s or the readhead's maximum speed, whichever is slowest.

## Incremental signal calibration

1. Cycle the power to the readhead or connect the 'Remote CAL' output pin to 0 V for < 3 seconds. The readhead will then single flash blue to indicate it is in calibration mode. The readhead will only enter calibration mode if the LED is flashing green.
2. Move the readhead at slow speed along the axis, ensuring that it does not pass a reference mark, until the LED starts double-flashing. This indicates that the incremental signals are now calibrated and the new settings are stored in the readhead memory.
3. The system is now ready for the reference mark phasing. For systems without a reference mark, cycle the power to the readhead or connect the 'Remote CAL' output pin to 0 V for < 3 seconds to exit the calibration mode.
4. If the system does not automatically enter the reference mark phasing stage (LED continues single flashing) the calibration of the incremental signals has failed. After ensuring failure is not due to overspeed, exit the calibration routine, restore the readhead's factory defaults (see '[Restoring factory defaults](#)' on page [33](#)) and check the readhead installation and system cleanliness before repeating the calibration routine.

## Reference mark phasing

1. Move the readhead back and forth over the reference mark until the LED stops flashing and remains solid blue. The reference mark is now phased.
2. The system automatically exits the calibration routine and is ready for operation.
3. AGC is automatically switched on once calibration is complete. To switch off AGC refer to '[Switching Automatic Gain Control \(AGC\) on or off](#)' on page [33](#).
4. If the LED continues double-flashing blue after repeatedly passing the reference mark it is not being detected.
  - Ensure that the readhead orientation and alignment are correct.

## Calibration routine manual exit

To exit the calibration routine at any stage cycle the power to the readhead or connect the 'Remote CAL' output pin to 0 V for < 3 seconds. The LED will then stop flashing.

## LED status during system calibration

LED	Settings stored
Blue single flashing	None, restore factory defaults and recalibrate
Blue double flashing	Incremental only
Blue (auto-complete)	Incremental and reference mark

**NOTE:** For full readhead LED diagnostics see page [34](#).

## Restoring factory defaults

When reinstalling the system, or in the case of continued calibration failure, factory defaults should be restored.

---

**NOTE:** Restoring factory defaults can also be carried out using the optional ADTi-100 and ADT View software. See [www.renishaw.com/adt](http://www.renishaw.com/adt) for more information.

---

### To restore factory defaults:

1. Switch system off.
2. Obscure the readhead optical window or connect the 'Remote CAL' output pin to 0 V.
3. Power the readhead.
4. Remove the obstruction or, if using, the connection from the 'Remote CAL' output pin to 0 V.
5. The readhead set-up LED will start continuously flashing indicating factory defaults have been restored and the readhead is in installation mode.
6. Repeat the system calibration (see '[System calibration](#)' on page [32](#)).

## Switching Automatic Gain Control (AGC) on or off

The AGC is automatically enabled once the system has been calibrated (indicated by a solid blue LED). AGC can be manually switched off by connecting the 'Remote CAL' output pin to 0 V for > 3 seconds < 10 seconds. The readhead set-up LED will then be solid green.

---

**NOTE:** AGC can be switched on or off using the optional ADTi-100 and ADT View software. See [www.renishaw.com/adt](http://www.renishaw.com/adt) for more information.

---

## Readhead LED diagnostics

Mode	LED	Status
Installation mode	Green flashing	Good set-up, maximise flash rate for optimum set-up
	Orange flashing	Poor set-up, adjust readhead to obtain green flashing LED
	Red flashing	Poor set-up, adjust readhead to obtain green flashing LED
Calibration mode	Blue single flashing	Calibrating incremental signals
	Blue double flashing	Calibrating reference mark
Normal operation	Blue	AGC on; optimum set-up
	Green	AGC off; optimum set-up
	Red	Poor set-up; signal may be too low for reliable operation
	Blank flash	Reference mark detected (visible indication at speed < 100 mm/s only)
Alarm	4 red flashes	Low signal or over signal; system in error

## Troubleshooting


Fault	Cause	Possible solutions
<b>LED on the readhead is blank</b>	There is no power to the readhead	<ul style="list-style-type: none"> <li>Check you have 5 V at the readhead</li> <li>For cable variants check correct wiring of connector</li> </ul>
<b>LED on the readhead is red and I can't get a green LED</b>	The signal strength is < 50%	<ul style="list-style-type: none"> <li>Check the readhead optical window and scale are clean and free from contamination</li> <li>Restore factory defaults (see page 33) and check alignment of the readhead. In particular:           <ul style="list-style-type: none"> <li>Rideheight</li> <li>Yaw</li> <li>Offset</li> </ul> </li> <li>Check the scale and readhead orientation</li> <li>Check that the readhead variant is the correct type for the chosen scale (see the <i>ATOM DX™ miniature encoder system</i> data sheet (Renishaw part no. L-9517-9736) for details of readhead configuration)</li> </ul>
<b>Unable to get a flashing Green LED over the complete axis length</b>	System run-out is not within specification	<ul style="list-style-type: none"> <li>Check that the readhead variant is the correct type for the chosen scale (see the <i>ATOM DX™ miniature encoder system</i> data sheet (Renishaw part no. L-9517-9736) for details of readhead configuration)</li> <li>Use a DTI gauge and check the run-out is within specifications</li> <li>Restore factory defaults</li> <li>Realign the readhead to obtain a flashing green LED at the mid-point of the run-out</li> <li>Recalibrate the system (see page 32)</li> </ul>
<b>Can't initiate the calibration routine</b>	Signal size is < 70%	<ul style="list-style-type: none"> <li>Restore factory defaults</li> <li>Realign the readhead to obtain a flashing green LED</li> </ul>

Fault	Cause	Possible solutions
<b>LED on the readhead remains single flashing blue even after moving it along the full axis length</b>	The system has failed to calibrate the incremental signals due to the signal strength being < 70%	<ul style="list-style-type: none"> <li>Exit CAL mode and restore factory defaults (see page 33)</li> <li>Check system set-up and realign the readhead to obtain a flashing green LED along the full axis of travel before recalibrating</li> </ul>
<b>During calibration the LED on the readhead is double flashing blue even after moving it past the reference mark several times</b>	The readhead is not seeing a reference mark	<ul style="list-style-type: none"> <li>Ensure you are moving the readhead past your chosen reference mark several times</li> <li>Check the scale/readhead orientation</li> <li>Check the scale/readhead alignment</li> <li>Check the readhead optical window and scale are clean and free from contamination</li> <li>Check that the readhead variant is the correct type for the chosen scale (see the <i>ATOM DX™ miniature encoder system</i> data sheet (Renishaw part no. L-9517-9736) for details of readhead configuration)</li> </ul>
<b>No reference mark output</b>		<ul style="list-style-type: none"> <li>Ensure you are not over-speeding the readhead during calibration mode (maximum speed &lt; 100 mm/s)</li> <li>Calibrate the system (see page 32) <ul style="list-style-type: none"> <li>If the system completes calibration mode then it has successfully seen and calibrated the reference mark. If you still don't see a reference mark then check the system wiring.</li> <li>If the system does not calibrate the reference mark (readhead set-up LED remains double flashing blue) see above for possible solutions</li> </ul> </li> </ul>
<b>Reference mark is not repeatable</b>	Only the chosen reference mark that has been used in the calibration sequence is repeatable; other reference marks may not be phased	<ul style="list-style-type: none"> <li>Ensure you are using the reference mark that has been calibrated for referencing your system</li> <li>The readhead bracket must be stable and not allow any mechanical movement of the readhead</li> <li>Check any unused reference marks have been deselected</li> <li>Clean the scale and the readhead optical window and check for damage then recalibrate the system (see page 32) over the chosen reference mark</li> </ul>

Fault	Cause	Possible solutions
<b>LED on the readhead is flashing red over the reference mark</b>	The reference mark is not phased	<ul style="list-style-type: none"> <li>• Ensure you are using the reference mark that has been calibrated for referencing your system as only this reference mark will be guaranteed to remain phased. The LED may flash red when passing other reference marks if they have not been deselected (see page 22)</li> <li>• Clean the scale and the readhead optical window and check for scratches then recalibrate the system over the chosen reference mark (see page 32)</li> </ul>
<b>Multiple reference marks output</b>	Unused reference marks have not been deselected	<ul style="list-style-type: none"> <li>• All unused reference marks should be deselected (see page 22) as only the calibrated reference mark will be repeatable</li> <li>• Check alignment of deselection stickers</li> </ul>

## ATOM DX cabled readhead dimensions



Dimensions and tolerances in mm



<sup>1</sup> Not the optical centreline

## ATOM DX top exit readhead dimensions

Dimensions and tolerances in mm



*Identification marks for readhead manufacture only.  
Notches will vary depending on readhead type.*


<sup>1</sup> Not the optical centreline

## Bracket dimensions


Dimensions and tolerances in mm



**'L' mounting bracket (A-9402-0037)**



**Side mount bracket (A-9401-0103)**



## Output signals

Function	Signal	Colour	Cabled				Top exit (readhead)
			9-way D-type (A)	15-way D-type (D)	15-way D-type alternative pin-out (H)	10-way JST <sup>1</sup> (K)	
Power	5 V	Brown	5	7, 8	4, 12	10	10
	0 V	White	1	2, 9	2, 10	2	9
Incremental	A	+	Red	2	14	1	9
		-	Blue	6	6	9	5
	B	+	Yellow	4	13	3	7
		-	Green	8	5	11	6
Reference mark	Z	+	Violet	3	12	14	8
		-	Grey	7	4	7	4
Alarm	E	-	Orange	-	3	13	6
Remote CAL <sup>3</sup>	CAL	Clear	9	1	5	3	2
Shield	-	Screen	Case	Case	Case	Ferrule	-

NOTE: Top exit cables are terminated with the 'K' pin-out or the 'D' pin-out dependent upon which top exit readhead cable is used.

<sup>1</sup> PCB mount mating connectors: Top entry (BM10B-SRSS-TB); Side entry (SM10B-SRSS-TB).

<sup>2</sup> Connector on top exit readhead only: Mating connector (10SUR - 32S).

<sup>3</sup> Remote CAL line must be connected for use with the ADTi-100.

# Speed

## 20 µm ATOM DX readhead

Clocked output option (MHz)	Maximum speed (m/s)										Minimum edge separation <sup>1</sup> (ns)	
	Readhead type											
	D (5 µm)	X (1 µm)	Z (0.5 µm)	W (0.2 µm)	Y (0.1 µm)	H (50 nm)	M (40 nm)	I (20 nm)	O (10 nm)	Q (5 nm)		
50	10	10	10	7.25	3.63	1.813	1.450	0.725	0.363	0.181	0.091	
40	10	10	10	5.80	2.90	1.450	1.160	0.580	0.290	0.145	0.073	
25	10	10	9.06	3.63	1.81	0.906	0.725	0.363	0.181	0.091	0.045	
20	10	10	8.06	3.22	1.61	0.806	0.645	0.322	0.161	0.081	0.040	
12	10	10	5.18	2.07	1.04	0.518	0.414	0.207	0.104	0.052	0.026	
10	10	8.53	4.27	1.71	0.85	0.427	0.341	0.171	0.085	0.043	0.021	
08	10	6.91	3.45	1.38	0.69	0.345	0.276	0.138	0.069	0.035	0.017	
06	10	5.37	2.69	1.07	0.54	0.269	0.215	0.107	0.054	0.027	0.013	
04	10	3.63	1.81	0.73	0.36	0.181	0.145	0.073	0.036	0.018	0.009	
01	4.53	0.91	0.45	0.18	0.09	0.045	0.036	0.018	0.009	0.005	0.002	
											1038	

<sup>1</sup> For a readhead with a 1 m cable.


## 40 µm ATOM DX readhead

Clocked output option (MHz)	Maximum speed (m/s)											Minimum edge separation <sup>1</sup> (ns)	
	Readhead type												
	T (10 µm)	D (5 µm)	G (2 µm)	X (1 µm)	Z (0.5 µm)	W (0.2 µm)	Y (0.1 µm)	H (50 nm)	M (40 nm)	I (20 nm)	O (10 nm)	Q (5 nm)	
50	20	20	20	20	18.13	7.25	3.63	1.813	1.450	0.725	0.363	0.181	25.1
40	20	20	20	20	14.50	5.80	2.90	1.450	1.160	0.580	0.290	0.145	31.6
25	20	20	20	18.13	9.06	3.63	1.81	0.906	0.725	0.363	0.181	0.091	51.0
20	20	20	20	16.11	8.06	3.22	1.61	0.806	0.645	0.322	0.161	0.081	57.5
12	20	20	20	10.36	5.18	2.07	1.04	0.518	0.414	0.207	0.104	0.052	90.0
10	20	20	17.06	8.53	4.27	1.71	0.85	0.427	0.341	0.171	0.085	0.043	109
08	20	20	13.81	6.91	3.45	1.38	0.69	0.345	0.276	0.138	0.069	0.035	135
06	20	20	10.74	5.37	2.69	1.07	0.54	0.269	0.215	0.107	0.054	0.027	174
04	20	18.13	7.25	3.63	1.81	0.73	0.36	0.181	0.145	0.073	0.036	0.018	259
01	9.06	4.53	1.81	0.91	0.45	0.18	0.09	0.045	0.036	0.018	0.009	0.005	1038


<sup>1</sup> For a readhead with a 1 m cable.

# Electrical connections

## Grounding and shielding



**IMPORTANT:** The shield should be connected to the machine earth (Field Ground). For JST variants the ferrule should be connected to the machine earth.



**IMPORTANT:** The shield should be connected to the machine earth (Field Ground).


**NOTE:** For Renishaw top exit readhead cables the shield connection is provided by the P-clip.

**Maximum readhead cable length:** 3 m

**Maximum extension cable length:** Dependent on cable type, readhead cable length and clock speed. Contact your local Renishaw representative for more information.

## Recommended signal termination

### Digital outputs




Standard RS422A line receiver circuitry.


The capacitors are recommended for improved noise immunity.

### Single-ended alarm signal termination

(Not available with 'A' cable termination)



## Remote CAL operation



Remote system calibration (CAL) is possible via the CAL pin.


# Output specifications

## Digital output signals

Form – Square wave differential line driver to EIA RS422A

### Incremental<sup>1</sup>

2 channels A and B in quadrature (90° phase shifted)



Resolution option code	P (µm)	S (µm)
T <sup>2</sup>	40	10
D	20	5
G <sup>2</sup>	8	2
X	4	1
Z	2	0.5
W	0.8	0.2
Y	0.4	0.1
H	0.2	0.05
M	0.16	0.04
I	0.08	0.02
O	0.04	0.01
Q	0.02	0.005
R <sup>3</sup>	0.01	0.0025

### Reference<sup>1</sup>



Synchronised pulse Z, duration as resolution.  
Bi-directionally repeatable.<sup>4</sup>

<sup>1</sup> For clarity, the inverse signals are not shown.


<sup>2</sup> 40 µm ATOM DX readheads only.

<sup>3</sup> 20 µm ATOM DX readheads only.

<sup>4</sup> Only the calibrated reference mark is bi-directionally repeatable.

### Alarm

**Line driven** (Asynchronous pulse)  
(Not available with 'A' cable termination)



Alarm asserted when:

- The signal amplitude is < 20% or > 135%
- The readhead speed is too high for reliable operation

### or 3-state alarm

Differentially transmitted signals forced open circuit for > 15 ms when alarm conditions valid.

## General specifications

<b>Power supply</b>	5 V –5%/+10%	Typically < 200 mA fully terminated Power from a 5 Vdc supply complying with the requirements for SELV of standard IEC 60950-1 200 mVpp maximum @frequency up to 500 kHz
<b>Temperature</b>	Storage	–20 °C to +70 °C
	Operating	0 °C to +70 °C
<b>Humidity</b>		95% relative humidity (non-condensing) to IEC 60068-2-78
<b>Sealing</b>		IP40
<b>Acceleration (system)</b>	Operating	400 m/s <sup>2</sup> , 3 axes
<b>Shock (system)</b>	Operating	1000 m/s <sup>2</sup> , 11 ms, ½ sine, 3 axes
<b>Vibration</b>	Operating	Sinusoidal 100 m/s <sup>2</sup> max @ 55 Hz to 2000 Hz, 3 axes
<b>Mass</b>	Cabled readhead	3.2 g
	Top exit readhead	2.9 g
	Cable	18 g/m
<b>Cable</b>	Cabled readhead	10 core, high flex, EMI screened cable, outside diameter 3.5 mm maximum Flex life > 20 × 10 <sup>6</sup> cycles at 20 mm bend radius, maximum length 3 m (Extension cable up to 25 m when using Renishaw approved extension cable) UL recognised component 
	Top exit readhead	Cables available in lengths from 0.5 m to 3 m with 15-way D-type or 10-way JST (SH) connector options
<b>Connector options</b>	Cabled readhead	9-way D-type 15-way D-type (standard and alternative pin out) 10-way JST (SH)
	Top exit readhead	10-way JST (SUR)
<b>Typical sub-divisional error (SDE)</b>	20 µm version	< ±75 nm
	40 µm version	< ±120 nm

**CAUTION:** Renishaw encoder systems have been designed to the relevant EMC standards, but must be correctly integrated to achieve EMC compliance. In particular, attention to shielding arrangements is essential.

## RTLF scale specifications

<b>Material</b>	Hardened and tempered martensitic stainless steel fitted with a self-adhesive backing tape
<b>Form (height x width)</b>	0.41 mm x 8 mm (including adhesive)
<b>Pitch</b>	20 µm or 40 µm
<b>Datum fixing</b>	Adhesive datum clamp A-9585-0028 secured with Loctite® 435™
<b>Reference mark</b> Positioning	Auto-phase optical reference mark repeatable to the unit of resolution throughout the specified speed and temperature range Customer deselectable reference marks at 50 mm spacing Reference mark in the centre for lengths < 100 mm
<b>Accuracy (at 20 °C)</b> RTLF20-S/RTLF40H-S	±5 µm/m
RTLF40-S	±15 µm/m
<b>Coefficient of thermal expansion (at 20 °C)</b>	10.1 ±0.2 µm/m/°C
<b>Length<sup>1</sup></b>	20 mm to 1 m in 10 mm increments 1 m to 10 m in 1 m increments <sup>2</sup>
<b>Mass</b>	12.2 g/m

<sup>1</sup> For information on how the substrate affects the axis, contact your local Renishaw representative.

<sup>2</sup> The recommended maximum axis length for 20 µm systems is 1 m.

[www.renishaw.com/contact](http://www.renishaw.com/contact)

 [#renishaw](#)

 +44 (0) 1453 524524

 [uk@renishaw.com](mailto:uk@renishaw.com)

© 2017-2026 Renishaw plc. All rights reserved. This document may not be copied or reproduced in whole or in part, or transferred to any other media or language by any means, without the prior written permission of Renishaw.  
RENISHAW® and the probe symbol are registered trade marks of Renishaw plc. Renishaw product names, designations and the mark 'apply innovation' are trade marks of Renishaw plc or its subsidiaries. Other brand, product or company names are trade marks of their respective owners. Renishaw plc. Registered in England and Wales. Company no: 1106260. Registered office: New Mills, Wotton-under-Edge, Glos, GL12 8JR, UK.

WHILE CONSIDERABLE EFFORT WAS MADE TO VERIFY THE ACCURACY OF THIS DOCUMENT AT PUBLICATION, ALL WARRANTIES, CONDITIONS, REPRESENTATIONS AND LIABILITY, HOWSOEVER ARISING, ARE EXCLUDED TO THE EXTENT PERMITTED BY LAW. RENISHAW RESERVES THE RIGHT TO MAKE CHANGES TO THIS DOCUMENT AND TO THE EQUIPMENT, AND/OR SOFTWARE AND THE SPECIFICATION DESCRIBED HEREIN WITHOUT OBLIGATION TO PROVIDE NOTICE OF SUCH CHANGES.

Part no.: M-9414-9899-01-B  
Issued: 01.2026