

# TONiC™ T1x3x RTLC20-S incremental linear encoder system



This page is intentionally left blank.

## Contents

Legal notices .....	5
Storage and handling .....	9
TONiC T1x3x readhead installation drawing .....	11
Ti/TD interface drawing .....	12
DOP interface drawing .....	13
RTLC20-S scale installation drawing .....	14
Equipment required for installing the RTLC20-S scale.....	15
Cutting the RTLC20-S scale.....	16
Applying the RTLC20-S scale .....	17
Fitting the end covers .....	18
Fitting the datum clamp .....	18
Reference mark selector and limit magnet installation.....	19
TONiC quick-start guide.....	20
System connection - Ti or TD interfaces.....	21
System connection - DOP interface .....	23
Readhead mounting and alignment .....	24
System LEDs .....	25
System calibration .....	26
Restoring factory defaults .....	28
Switching Automatic Gain Control (AGC) on or off.....	28
Output signals.....	29
Speed .....	32
Electrical connections .....	33
General specifications .....	41

RTLC20-S scale specifications . . . . .	42
Reference mark . . . . .	42
Limit switches . . . . .	42

## Legal notices

### Patents

Features of Renishaw's TONiC™ and RTLC20-S encoder systems are the subjects of the following patents and patent applications:

EP0748436	US5861953	EP1173731	US6775008B2	JP4750998
CN100543424C	US7659992	JP4932706	CN100507454C	US7550710
EP1766335	CN101300463B	EP1946048	US7624513B2	JP5017275
CN101310165B	US7839296	EP1957943	US8141265	EP2294363
CN102057256	JP5475759	JP5755299	KR20110033204	CN1314511
EP1469969	JP5002559	US8466943	US8987633	

### Terms and conditions and warranty

Unless you and Renishaw have agreed and signed a separate written agreement, the equipment and/or software are sold subject to the Renishaw Standard Terms and Conditions supplied with such equipment and/or software, or available on request from your local Renishaw office.

Renishaw warrants its equipment and software for a limited period (as set out in the Standard Terms and Conditions), provided that they are installed and used exactly as defined in associated Renishaw documentation. You should consult these Standard Terms and Conditions to find out the full details of your warranty.

Equipment and/or software purchased by you from a third-party supplier is subject to separate terms and conditions supplied with such equipment and/or software. You should contact your third-party supplier for details.

### Declaration of Conformity

Renishaw plc hereby declares that the TONiC encoder system is in compliance with the essential requirements and other relevant provisions of:

- the applicable EU directives
- the relevant statutory instruments under UK law



The full text of the declaration of conformity is available at: [www.renishaw.com/productcompliance](http://www.renishaw.com/productcompliance).

### Compliance

#### Federal Code Of Regulation (CFR) FCC Part 15 – RADIO FREQUENCY DEVICES

##### 47 CFR Section 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

##### 47 CFR Section 15.21

The user is cautioned that any changes or modifications not expressly approved by Renishaw plc or authorised representative could void the user's authority to operate the equipment.

##### 47 CFR Section 15.105

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## 47 CFR Section 15.27

This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to ensure compliance.

## Supplier's Declaration of Conformity

## 47 CFR § 2.1077 Compliance Information

Unique Identifier: TONiC

### Responsible Party - U.S. Contact Information

Renishaw Inc.  
1001 Wesemann Drive  
West Dundee  
Illinois  
IL 60118  
United States  
Telephone number: +1 847 286 9953  
Email: [usa@renishaw.com](mailto:usa@renishaw.com)

### ICES-003 – Information Technology Equipment (including Digital Apparatus)

This ISM device complies with Canadian ICES-003(A).

Cet appareil ISM est conforme à la norme ICES-003(A).

## Intended use

The TONiC encoder system is designed to measure position and provide that information to a drive or controller in applications requiring motion control. It must be installed, operated, and maintained as specified in Renishaw documentation and in accordance with the Standard Terms and Conditions of the Warranty and all other relevant legal requirements.

## Further information

Further information relating to the TONiC and RTLC20-S encoder range can be found in the following documents:

<i>TONiC™ encoder system data sheet (Renishaw part no. L-9517-9337)</i>
<i>TONiC™ UHV encoder system data sheet (Renishaw part no. L-9517-9426)</i>
<i>TONiC™ DOP (dual output) encoder system data sheet (Renishaw part no. L-9517-9411)</i>
<i>RTLC incremental linear scale data sheet (Renishaw part no. L-9517-9417)</i>

These can be downloaded from our website at [www.renishaw.com/tonicdownloads](http://www.renishaw.com/tonicdownloads) and are also available from your local Renishaw representative.

## Packaging

The packaging of our products contains the following materials and can be recycled.

Packing component	Material	ISO 11469	Recycling guidance
Outer box	Cardboard	Not applicable	Recyclable
	Polypropylene	PP	Recyclable
Inserts	Low density polyethylene foam	LDPE	Recyclable
	Cardboard	Not applicable	Recyclable
Bags	High density polyethylene bag	HDPE	Recyclable
	Metalised polyethylene	PE	Recyclable

## REACH regulation

Information required by Article 33(1) of Regulation (EC) No. 1907/2006 ("REACH") relating to products containing substances of very high concern (SVHCs) is available at [www.renishaw.com/REACH](http://www.renishaw.com/REACH).

## Disposal of waste electrical and electronic equipment



The use of this symbol on Renishaw products and/or accompanying documentation indicates that the product should not be mixed with general household waste upon disposal. It is the responsibility of the end user to dispose of this product at a designated collection point for waste electrical and electronic equipment (WEEE) to enable reuse or recycling. Correct disposal of this product will help to save valuable resources and prevent potential negative effects on the environment. For more information, contact your local waste disposal service or Renishaw distributor.

## TONiC software notices

### Third party licences

Copyright © 2019, Microchip Technology Inc. and its subsidiaries ("Microchip")

All rights reserved.

This software is developed by Microchip Technology Inc. and its subsidiaries ("Microchip").

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Microchip's name may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY MICROCHIP "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL MICROCHIP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA OR PROFITS; OR BUSINESS INTERRUPTION) HOWSOEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

### US government notice

NOTICE TO UNITED STATES GOVERNMENT CONTRACT AND PRIME CONTRACT CUSTOMERS

This software is commercial computer software that has been developed by Renishaw exclusively at private expense. Notwithstanding any other lease or licence agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government and/or its prime contractors regarding its use, reproduction and disclosure are as set forth in the terms of the contract or subcontract between Renishaw and the United States Government, civilian federal agency or prime contractor respectively. Please consult the applicable contract or subcontract and the software licence incorporated therein, if applicable, to determine your exact rights regarding use, reproduction and/or disclosure.




### Renishaw End User Licence Agreement (EULA)

Renishaw software is licensed in accordance with the Renishaw licence at:


[www.renishaw.com/legal/softwareterms](http://www.renishaw.com/legal/softwareterms).

## Storage and handling

TONiC non-contact optical encoder systems provide good immunity against contaminants such as dust, fingerprints and light oils. However, in harsh environments such as machine tool applications, use protection to prevent ingress of coolant or oil.




### Minimum bend radius






**NOTE:** During storage ensure the self-adhesive tape is on the outside of the bend.

## Scale and readhead



## Readhead only







## Temperature

Storage	
System	-20 °C to +70 °C


Bakeout	
UHV readhead	+120 °C

Operating	
System	0 °C to +70 °C




## Humidity

95% relative humidity (non-condensing) to IEC 60068-2-78



## TONiC T1x3x readhead installation drawing

Dimensions and tolerances in mm





<sup>1</sup> Extent of mounting faces.

<sup>2</sup> The dynamic bend radius is not applicable for UHV cables. UHV cables are for static use only.

<sup>3</sup> The UHV cable diameter is approximately 3 mm.


<sup>4</sup> Dimension from substrate.

<sup>5</sup> The recommended thread engagement is 5 mm minimum (7.5 mm including counterbore) and the recommended tightening torque is 0.25 Nm to 0.4 Nm.



## Ti/TD interface drawing

Dimensions and tolerances in mm



## CAL button operation

Function	Operation
Calibration (CAL) routine enable/disable	Push and release (< 3 seconds)
Automatic Gain Control (AGC) enable/disable	Push and release (> 3 seconds)
Restore factory defaults	Push and hold during power 'Off/On' cycle


### NOTES:

- For full readhead and interface LED diagnostics, see 'System LEDs' on page 25.
- Only the readhead is UHV compatible. The Ti/TD interface must be kept outside of the vacuum chamber.

<sup>1</sup> The dynamic bend radius is not applicable for UHV cables. UHV cables are for static use only.

## DOP interface drawing

Dimensions and tolerances in mm



### CAL button operation


Function	Operation
Calibration (CAL) routine enable/disable	Push and release (< 3 seconds)
Automatic Gain Control (AGC) enable/disable	Push and release (> 3 seconds)
Restore factory defaults	Push and hold during power 'Off/On' cycle

### NOTES:

- For full readhead and interface LED diagnostics, see 'System LEDs' on page 25.
- Only the readhead is UHV compatible. The DOP interface must be kept outside of the vacuum chamber.

# RTLC20-S scale installation drawing

Dimensions and tolerances in mm




## NOTES:

- The reference mark selector and limit actuator locations are correct for the readhead orientation shown.
- External magnetic fields greater than 6 mT, in the vicinity of the readhead, may cause false activation of the limit and reference sensors.

<sup>1</sup> Dimension from substrate.

<sup>2</sup> Supplied with 2 × M2 × 4 screws.

## Alternative bolted reference mark selector and limit magnets



## Equipment required for installing the RTLC20-S scale

### Required parts:

- Appropriate length of RTLC20-S scale (see 'RTLC20-S scale installation drawing' on page 14)
- Side mount scale applicator (A-9589-0115) or top mount scale applicator (A-9589-0094)
- Datum clamp (A-9585-0028)
- Loctite® 435™ (P-AD03-0012)
- Appropriate cleaning solvents (see 'Storage and handling' on page 9)
- 2 × M2.5 screws
- Green shim (supplied with TONiC readhead)
- Lint-free cloth

### Optional parts:

- End cover kit (A-9585-0035)
- Renishaw scale wipes (A-9523-4040)
- Guillotine (A-9589-0071) or shears (A-9589-0133) for cutting RTLC20-S to length required
- Magnet applicator tool (A-9653-0201)
- Loctite 435 dispensing tip (P-TL50-0209)
- Reference mark and limit magnets; see table below

Magnet type	Part number	
	Adhesive mounted magnets (standard)	Bolted magnets
Reference mark selector <sup>1</sup>	A-9653-0143	A-9653-0290
Q limit	A-9653-0139	A-9653-0291
P limit	A-9653-0138	A-9653-0292

<sup>1</sup> The reference mark selector magnet is only required for 'Customer selectable reference mark' readheads. For more information refer to *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337).

## Cutting the RTLC20-S scale

If required cut the RTLC20-S scale to length using a guillotine or shears.


### Using the guillotine

The guillotine should be held securely in place, using a suitable vice or clamping method.

Once secured, feed the RTLC20-S scale through the guillotine as shown, and place the guillotine press block down onto the scale.

**NOTE:** Ensure the block is in the correct orientation (as shown below).


### Guillotine press block orientation when cutting RTLC20-S scale



Whilst holding the block in place, in a smooth motion, pull down the lever to cut through the scale.

### Using the shears

Feed the RTLC20-S scale through the centre aperture on the shears (as shown).




Hold the scale in place and close the shears in a smooth motion to cut through the scale.

## Applying the RTLC20-S scale


There are two versions of scale applicator for use with the RTLC20-S scale; side mount and top mount. The side mount version is shown below, but the application method is the same for both versions of the scale applicator.

1. Allow the scale to acclimatise to the installation environment prior to installation.
2. Mark out the start position for the scale on the axis substrate ensuring that there is enough room for the optional end covers if required (see '[RTLC20-S scale installation drawing](#)' on page [14](#)).
3. Thoroughly clean and degrease the substrate using the recommended solvents (see '[Storage and handling](#)' on page [9](#)). Allow the substrate to dry before applying the scale.
4. Mount the appropriate scale applicator to the readhead mounting bracket. Place the green shim supplied with the readhead between the applicator and the substrate to set the nominal height.




**NOTE:** The scale applicator can be mounted either way round to enable the easiest orientation for the installation of the scale.

5. Move the axis to the start of travel leaving enough room for the scale to be inserted through the applicator, as shown below.
6. Begin to remove the backing paper from the scale and insert the scale into the applicator up to the start position. Ensure the backing tape is routed under the splitter screw.



7. Apply firm finger pressure via a clean, dry, lint-free cloth to ensure the scale end adheres well to the substrate.
8. Slowly and smoothly move the applicator through the entire axis of travel. Ensure the backing paper is pulled manually from the scale and does not catch under the applicator.

Direction of scale application




9. During installation ensure the scale adheres to the substrate using light finger pressure.
10. Remove the applicator and, if necessary, adhere the remaining scale manually.
11. Apply firm finger pressure via a clean, dry, lint-free cloth along the length of the scale after application to ensure complete adhesion.
12. Clean the scale using Renishaw scale cleaning wipes or a clean, dry, lint-free cloth.
13. Fit the optional end covers if required (see '[Fitting the end covers](#)' on page [18](#)).
14. Allow 24 hours for complete adhesion of the scale before fitting the datum clamp (see '[Fitting the datum clamp](#)' on page [18](#)).

## Fitting the end covers


The end cover kit is designed to be used with the RTLC20-S scale to provide protection for exposed scale ends.

**NOTE:** The end covers are optional and can be fitted before or after readhead installation.

1. Remove the backing tape from the adhesive tape on the back of the end cover.



2. Align markers on the edges of the end cover with the end of the scale and place the end cover over the scale.



**NOTE:** There will be a gap between the end of the scale and the adhesive tape on the end cover.

## Fitting the datum clamp


**IMPORTANT:** Allow 24 hours after scale application before fitting the datum clamp.

The datum clamp fixes the RTLC20-S scale rigidly to the substrate at the location chosen.


**CAUTION:** The metrology of the system may be compromised if the datum clamp is not used.

The datum clamp does not need to be fitted adjacent to a reference mark. It can be positioned anywhere along the axis depending upon the customers' requirements.

1. Remove the backing paper from the datum clamp.
2. Place the datum clamp with cut-out against the scale at the chosen location.



3. Place a small amount of adhesive (Loctite® 435™) in the cut-out on the datum clamp, ensuring one of the adhesive wicks onto the scale surface. Dispensing tips for the adhesive are available.



Ensure the adhesive wicks along the entire length of the cut-out.

## Reference mark selector and limit magnet installation


**IMPORTANT:** Allow 24 hours after the scale application before fitting the magnets.

As the readhead passes the reference mark selector magnet or limit switch magnet, a force of up to 0.2 N is generated between the magnet and the concentrators on the readhead.

- The design of the bracket should be sufficiently stiff so that it is able to tolerate such force without distorting.
- Fitting the scale according to the instructions in this manual prevents the magnetic force from disturbing the scale.

Use the applicator tool to position the reference mark selector and limit magnets accurately and easily.


1. Attach the magnet to the applicator tool as shown.
2. Remove the self-adhesive backing paper from the magnet.



### NOTES:

- The limit output is nominally asserted when the readhead limit switch sensor passes the limit magnet leading edge, but can trigger up to 3 mm before that edge (see '[RTLC20-S scale installation drawing](#)' on page 14).
- The reference and limit magnets may creep when influenced by magnetic materials in close proximity. In such cases, use an additional fillet of epoxy glue or similar along the outer edge of the magnet assembly to hold them in place. Alternative bolted reference and limit magnets are available (see '[Optional parts:](#)' on page 15).
- External magnetic fields greater than 6 mT, in the vicinity of the readhead, may cause false activation of the limit and reference sensors.

3. Place the magnet in the chosen location alongside the edge of the scale ensuring that it is not mounted on the scale.
  - Limit magnets can be positioned at any user defined location along the axis length.
  - Position the reference mark selector magnet adjacent to the selected IN-TRAC reference mark as shown.<sup>1</sup>



**NOTE:** The reference mark selector and limit actuator locations are correct for the readhead orientation shown.

4. Press the magnet down firmly using a clean, dry, lint-free cloth for complete adhesion.

<sup>1</sup> The reference mark selector magnet is only required for 'Customer selectable reference mark' readheads. For more information refer to *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337).

# TONiC quick-start guide

This section is a quick-start guide to installing a TONiC system. More detailed information on installing the system is contained on pages 21 to page 28 of this installation guide.

## INSTALLATION

Ensure the scale, readhead optical window and mounting faces are clean and free from obstructions.



If required, ensure that the reference mark selector magnet is correctly positioned (see '[RTLC20-S scale installation drawing](#)' on page 14).



Plug the readhead cable into the Ti, TD or DOP interface under the cover plate and reassemble the interface (see '[System connection - Ti or TD interfaces](#)' on page 21 or '[System connection - DOP interface](#)' on page 23).

Connect to the receiving electronics and power-up.



Ensure AGC is switched off; the CAL LED on the readhead should be off (if not press and hold the CAL button on the interface until the CAL LED on the readhead switches off).



Install and align the readhead to maximise signal strength over the full axis of travel as indicated by the readhead and interface set-up LEDs (readhead - green; interface - ideally blue/purple).<sup>1</sup>

<sup>1</sup> Analogue Ti interfaces do not have a set-up LED.

## CALIBRATION

Press and release the CAL button on the interface. The CAL LED on the readhead will be single flashing.



Move the readhead along the scale at slow speed (< 100 mm/s), without passing a reference mark, until the LED starts double-flashing.



### No reference mark

If a reference mark is not being used, the calibration routine should now be exited by pressing and releasing the CAL button. The CAL LED will stop flashing. (Incremental CAL values are automatically stored)

### Reference mark

Move the readhead back and forth over the selected reference mark until the CAL LED stops flashing and remains 'off'. (Incremental and reference mark CAL values are automatically stored)



The system is now calibrated and ready for use. AGC can now be switched on if required by pressing and holding the CAL button until the CAL LED on the readhead switches on. CAL values and AGC status are stored in the TONiC readheads non-volatile memory at power down.

**NOTE:** If calibration fails, restore factory defaults (see '[Restoring factory defaults](#)' on page 28) and repeat the installation and calibration routine.


## System connection - Ti or TD interfaces

Approved ESD precautions must be followed at all times during readhead and interface electrical connections.



The readhead is connected to the Ti or TD interface via a small, rugged connector to allow for easy feed-through during installation.

### Connecting the readhead


- Remove the cover plate as shown (2 × M2.5 hex head screws).



- Taking care not to touch the pins, plug the connector into the socket in the interface, ensuring correct orientation as shown.




- Refit the cover plate ensuring the cable ferrule is located in the recess on the inside and no wires are trapped under the cover plate.



## Disconnecting the readhead

- Remove the cover plate on the interface (2 x M2.5 hex head screws).
- Gently lever the connector PCB (on the end of the cable) out of the socket. Do not pull the cable to remove the connector.



- Place the connector in an anti-static bag.
- Refit the cover plate.


## System connection - DOP interface

Approved ESD precautions must be followed at all times during readhead and interface electrical connections.

The readhead is connected to the DOP interface via a small, rugged connector to allow for easy feed-through during installation.

### Connecting the readhead

1. Remove the cover plate as shown (2 M2.5 hex head screws).
2. Taking care not to touch the pins, plug the connector into the socket in the interface, ensuring correct orientation as shown.
3. Refit the cover plate ensuring the cable ferrule is located in the recess on the inside and no wires are trapped under the cover plate.



### DOP interface mounting

The DOP interface can be DIN rail mounted or mounted to a suitable surface using customer-supplied screws.

---

#### NOTES:

- The recommended screw type M3 x 0.5 and must comply with: ISO 4762/DIN 912 grade 8.8 minimum/ANSI B18.3.1M.
- No washer is required under the screw head.
- The minimum thread engagement is 6 mm.
- The tightening torque should be between 0.9 Nm and 1.1 Nm.
- The DIN rail mounting, where used, must comply with EN 50022.

---

### Disconnecting the readhead

1. Remove the cover plate on the interface (2 M2.5 hex head screws).
2. Gently lever the connector PCB (on the end of the cable) out of the socket. Do not pull the cable to remove the connector.
3. Place the connector in an anti-static bag.
4. Refit the cover plate.

# Readhead mounting and alignment

## Mounting brackets

The bracket must have a flat mounting surface and should provide adjustment to enable conformance to the installation tolerances, allow adjustment to the rideheight of the readhead, and be sufficiently stiff to prevent deflection or vibration of the readhead during operation.

## Readhead set-up

Ensure that the scale, readhead optical window and mounting face are clean and free from obstructions.

**NOTE:** When cleaning the readhead and the scale apply the cleaning fluid sparingly, do not soak.


1. Mount the readhead to the bracket using 2 M2.5 screws.
2. To set the nominal rideheight, place the green spacer with the aperture under the optical centre of the readhead to allow normal LED function during set-up procedure.
3. Adjust the readhead to maximise the signal strength and achieve a green set-up LED on the readhead (> 70% signal) and a blue LED on the interface <sup>1</sup> along the full axis of travel.

**NOTE:** The readhead should be installed and set-up with the AGC switched off (CAL LED off). When reinstalling the readhead the factory defaults should be restored (see 'Restoring factory defaults' on page 28).

### Readhead set-up LED status




**NOTE:** For full readhead and interface LED diagnostics, see 'System LEDs' on page 25.




### Interface set-up LED status <sup>1</sup>



### Ti or TD interface LED



### DOP interface LEDs



<sup>1</sup> Analogue Ti interfaces do not have a set-up LED.

## System LEDs

### TONiC readhead LED diagnostics

LED		Indication	Status
Set-up	Incremental	Green	Normal set-up: signal level > 70%
		Orange	Acceptable set-up; signal level 50% to 70%
		Red	Poor set-up; signal may be too low for reliable operation; signal level < 50%
	Reference mark	Green (flash) <sup>1</sup>	Normal phasing
		Orange (flash)	Acceptable phasing
		Red (flash)	Poor phasing; clean scale and recalibrate if required
CAL	Operating	On	Automatic Gain Control – On
		Off	Automatic Gain Control – Off
	Calibration	Single-flashing	Calibrating incremental signals
		Double-flashing	Calibrating reference mark
	Reset	Flashing at power-up (< 2s)	Restore factory defaults

### Ti, TD or DOP interface LED diagnostics<sup>2</sup>

Signal	Indication	Status	Alarm output <sup>3</sup>
Incremental	Purple	Normal setup; signal level 110% to 135%	No
	Blue	Optimum setup; signal level 90% to 110%	No
	Green	Normal set-up: signal level 70% to 90%	No
	Orange	Acceptable set-up; signal level 50% to 70%	No
	Red	Poor set-up; signal may be too low for reliable operation; signal level < 50%	No
	Red / blank - flashing	Poor set-up; signal level < 20%; system in error	Yes
	Blue / blank - flashing	Over speed; system in error	Yes
	Purple / blank - flashing	Over signal; system in error	Yes
Reference mark	Blank flash	Reference mark detected (speed < 100 mm/s only)	No

<sup>1</sup> The flash will effectively be invisible when passing the reference mark if the incremental signal is > 70%.

<sup>2</sup> Analogue Ti interfaces do not have a set-up LED.

<sup>3</sup> The alarm output will take the form of 3-state or line driven E- signal depending on the interface configuration.

#### NOTES:

- Momentary status only, while the fault condition remains.
- The alarm may result in an axis position error; re-datum to continue.
- Some Ti interfaces do not output overspeed alarm.

See the product nomenclature for interface configuration in the *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337). This can be downloaded from our website at [www.renishaw.com/tonicdownloads](http://www.renishaw.com/tonicdownloads) and is also available from your local Renishaw representative.

# System calibration

Calibration is an essential operation that completes readhead set-up, with the optimum incremental and reference mark signal settings stored in the readhead's non-volatile memory.

## Before system calibration:

1. Ensure the scale and readhead optical window are clean (contamination around the reference mark may result in reference mark dephasing).
2. If reinstalling, restore factory defaults (see '[Restoring factory defaults](#)' on page [28](#)).
3. Ensure Automatic Gain Control is switched off (CAL LED on readhead is not illuminated) before beginning calibration (see '[Switching Automatic Gain Control \(AGC\) on or off](#)' on page [28](#)).
4. Ensure signal strength has been optimised over the full axis of travel; the readhead LED will be green.

---

### NOTES:


- During calibration the speed should not exceed 100 mm/s or the readheads maximum speed, whichever is slowest.
- The TD interface can be calibrated in either resolution.

---


## Incremental signal calibration

1. Press and release the CAL button on the end of the interface (for < 2 seconds) using a 2 mm allen key or similar tool.

Ti or TD interface



DOP interface



**WARNING:** Activating the CAL switch only requires 2.5 N force. Applying excess force may permanently damage the switch.

The CAL LED will now periodically single-flash to indicate that it is in incremental signal calibration mode.

2. Move the readhead along the axis, ensuring you do not pass the selected reference mark until the CAL LED starts double-flashing. This indicates the incremental signal is now calibrated and the new settings are stored in the readhead memory.

The system is now ready for reference mark phasing.

3. For systems without a reference mark, exit the calibration routine (see 'Calibration routine – manual exit')
4. If the system does not automatically enter the reference mark phasing stage (no double-flashing of the CAL LED) the calibration of the incremental signals has failed.
  - Ensure failure is not due to overspeed (> 100 mm/s or exceeding the readhead maximum speed),
  - Exit the calibration routine and restore factory defaults (see 'Restoring factory defaults' on page 28).
  - Check the readhead installation and system cleanliness and repeat the calibration routine.

## Reference mark phasing

1. Move the readhead back and forth over the selected reference mark until the CAL LED stops flashing and remains off. The reference mark is now phased.

**NOTE:** Only the chosen reference mark that has been used in the calibration routine is guaranteed to remain phased.

The system automatically exits the CAL routine and is ready for operation.

2. If the CAL LED continues double-flashing after passing the chosen reference mark many times, it is not detecting the reference mark.
  - Ensure that the correct readhead configuration is being used. Readheads can either output all reference marks or only output a reference mark where a reference selector magnet is fitted depending on the options chosen when ordering.
  - Check the reference mark selector magnet is fitted in the correct location relative to readhead orientation (see 'RTLC20-S scale installation drawing' on page 14).

## Calibration routine – manual exit

1. To exit the calibration routine at any stage press the CAL button. The CAL button will stop flashing.

## LED status during system calibration

CAL LED	Settings stored
Single flashing	None, restore factory defaults and recalibrate
Double flashing	Incremental only
Off (auto-complete)	Incremental and reference mark

## Restoring factory defaults

When realigning the readhead, reinstalling the system, or in the case of continued calibration failure, factory defaults must be restored.

### To restore factory defaults:

- Switch system off.
- Press and hold the CAL button whilst switching the system on. The CAL LED on the readhead will flash several times, indicating that the factory defaults have been restored.
- Release the CAL button.
- Check the '[Readhead mounting and alignment](#)' on page [24](#) and recalibrate the system (see '[System calibration](#)' on page [26](#)).

**NOTE:** System must be re-calibrated after restoring factory defaults.

## Switching Automatic Gain Control (AGC) on or off

The AGC can be switched on or off via the interface.

- Press and hold the CAL button on the interface for > 3 seconds to switch AGC on or off. The CAL LED on the readhead will be illuminated when AGC is active.

**NOTE:** The system must be calibrated before switching AGC on (see '[System calibration](#)' on page [26](#)).


# Output signals

## Analogue outputs

### Readhead output

Function	Output type		Signal	Colour	
Power	-		5 V Power	Brown	
			0 V Power	White	
Incremental signals	Analogue	Cosine	$V_1$	+ -	Red Blue
			$V_2$	+ -	Yellow Green
		Sine	$V_0$	+ -	Violet Grey
			$V_p$		Pink
Limits	Open collector		$V_q$		Black
			$V_x$		Clear
Calibrate	-		CAL	Orange	
Shield	-		Inner shield <sup>1</sup>	Green/Yellow	
	-		Outer shield	Outer screen	

### Interface output (analogue Ti0000 only)

Function	Output type		Signal	Pin	
Power	-		5 V Power	4	
			5 V Sense	5	
			0 V Power	12	
			0 V Sense	13	
Incremental signals	Analogue	Cosine	$V_1$	+ -	9 1
			$V_2$	+ -	10 2
		Sine	$V_0$	+ -	3 11
			$V_p$		7
Limits	Open collector		$V_q$		8
			$V_x$		6
Set-up	-		CAL	14	
Shield	-		Inner shield	Not connected	
	-		Outer shield	Case	
 15 way D-type plug					

<sup>1</sup> There is no inner shield on UHV cables.

## Digital outputs

### Interface output (digital Ti0004 to Ti20KD and TD4000 to TD0040)


Function	Output type	Signal	Interface	
			Ti0004 - Ti20KD	TD4000 - TD0040
Power	-	5 V	7, 8	7, 8
		0 V	2, 9	2, 9
Incremental	RS422A digital	A	+	14
			-	6
		B	+	13
			-	5
Reference mark	RS422A digital	Z	+	12
			-	4
Limits	Open collector	P <sup>1</sup>		11
		Q		10
Set-up	RS422A digital	X		1
Alarm <sup>2</sup>	-	E	+	-
			-	3
Resolution switching <sup>3</sup>	-	-		10
Shield	-	Inner shield		-
	-	Outer shield		Case
			 15-way D-type plug	

<sup>1</sup> Becomes alarm (E+) for Ti options E, F, G, H.

<sup>2</sup> The alarm signal can be output as a line driver signal or 3-state. Select the preferred option at time of ordering.

<sup>3</sup> On TD interfaces pin 10 should be connected to 0 V to switch to lower resolution.

## DOP interface output

Function	Output type	Signal		Pin	
Power	-	5 V Power		26	
		5 V Sense		18	
		0 V Power		9	
		0 V Sense		8	
Incremental signals	RS422A digital	A	+	24	
			-	6	
		B	+	7	
			-	16	
	Analogue	Cosine	V <sub>1</sub>	+	1
			V <sub>1</sub>	-	19
		Sine	V <sub>2</sub>	+	2
			V <sub>2</sub>	-	11
		RS422A digital	Z	+	15
				-	23
Reference mark	Analogue	V <sub>0</sub>	V <sub>0</sub>	+	12
				-	20
		E	E	+	25
				-	17
Limits	Open collector	P		4	
		Q		13	
Readhead set-up	-	X		10	
Shield	-	Inner shield		Not connected	
	-	Outer shield		Case	
				26-way high-density D-type plug	


## Speed

Clocked output option (MHz)	Maximum speed (m/s)										
	Ti0004 and DOP0004 5 µm	Ti0020 and DOP0020 1 µm	Ti0040 and DOP0040 0.5 µm	Ti0100 and DOP100 0.2 µm	Ti0200 and DOP200 0.1 µm	Ti0400 and DOP0400 50 nm	Ti1000 and DOP1000 20 nm	Ti2000 and DOP2000 10 nm	Ti4000 and DOP4000 5 nm	Ti10KD and DOP10KD 2 nm	Ti20KD and DOP20KD 1 nm
50	10	10	10	6.48	3.24	1.62	0.648	0.324	0.162	0.0654	0.032
40	10	10	10	5.40	2.70	1.35	0.540	0.270	0.135	0.054	0.027
25	10	10	8.10	3.24	1.62	0.810	0.324	0.162	0.081	0.032	0.016
20	10	10	6.75	2.70	1.35	0.675	0.270	0.135	0.068	0.027	0.013
12	10	9	4.50	1.80	0.900	0.450	0.180	0.090	0.045	0.018	0.009
10	10	8.10	4.05	1.62	0.810	0.405	0.162	0.081	0.041	0.016	0.0081
08	10	6.48	3.24	1.29	0.648	0.324	0.130	0.065	0.032	0.013	0.0065
06	10	4.50	2.25	0.90	0.450	0.225	0.090	0.045	0.023	0.009	0.0045
04	10	3.37	1.68	0.67	0.338	0.169	0.068	0.034	0.017	0.0068	0.0034
01	4.2	0.84	0.42	0.16	0.084	0.042	0.017	0.008	0.004	0.0017	0.0008
Analogue output (Ti0000)	10 (-3dB)										

NOTE: TD interface maximum speeds are resolution dependent as defined above.

## Electrical connections

### Grounding and shielding - standard TONiC system




**IMPORTANT:** The outer shield should be connected to the machine earth (Field Ground). The inner shield should be connected to 0 V at the receiving electronics only. Care should be taken to ensure that the inner and outer shields are insulated from each other. If the inner and outer shields are connected together, this will cause a short between 0 V and earth, which could cause electrical noise issues.

#### NOTES:

- The maximum cable length between the readhead and the interface is 10 m
- The maximum extension cable is dependent on the cable type, the readhead cable length and the clock speed. Contact your local Renishaw representative for more information.
- For DOP interfaces the external earthing tag on the interface must be used when mounting the interface on a DIN rail.

## Grounding and shielding - Ultra-high vacuum (UHV) TONiC system




**IMPORTANT:** The outer shield should be connected to the machine earth (Field Ground). The inner shield should be connected to 0 V at receiving electronics only. Care should be taken to ensure that the inner and outer shields are insulated from each other. If the inner and outer shields are connected together, this will cause a short between 0 V and earth, which could cause electrical noise issues.

### NOTES:

- The maximum cable length between the readhead and the interface is 10 m
- The maximum extension cable is dependent on the cable type, the readhead cable length and the clock speed. Contact your local Renishaw representative for more information.
- For DOP interfaces the external earthing tag on the interface must be used when mounting the interface on a DIN rail.

## Recommended signal termination


Ti digital, TD and DOP interfaces only <sup>1</sup>



Standard RS422A line receiver circuitry.

The capacitors are recommended for improved noise immunity.


Ti digital single-ended alarm signal termination <sup>2</sup>




<sup>1</sup> Ti digital interface with 'options' E, F, G, or H selected (differential alarm options). See 'Ti interface part numbers' in the *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337).

<sup>2</sup> Ti digital interface with 'options' A, B, C, or D selected (single-ended alarm options). See 'Ti interface part numbers' in the *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337).

### Analogue outputs




### Limit outputs<sup>1</sup>




**NOTE:** Select the resistor R so that the maximum current does not exceed 20 mA.  
Alternatively use a suitable relay or opto-isolator.

### Remote CAL operation (Analogue versions only)



All Ti, TD and DOP interfaces include a push button switch to enable CAL/AGC features. However, remote operation of the CAL/AGC is possible via pin 14 of analogue Ti0000 interfaces. For applications where no interface is used, remote operation of CAL/AGC is essential.

### TD interface resolution switching



Connect pin 10 to 0 V to switch to lower resolution.

<sup>1</sup> No limits on TD interfaces.

## Output specifications


### Digital output signals

#### Ti digital, TD and DOP interfaces only

Form – Square wave differential line driver to EIA RS422A (except limits P and Q)


##### Incremental<sup>1</sup>

Two channels A and B in quadrature (90° phase shifted)



Interface model	P (μm)	S (μm)
Ti0004 and DOP0004	20	5
Ti0020, TD0040, and DOP0020	4	1
Ti0040, TD0040, and DOP0040	2	0.5
Ti0100, TD0200, and DOP0100	0.8	0.2
Ti0200, TD0200, TD0400, and DOP0200	0.4	0.1
Ti0400, TD0400, and DOP0400	0.2	0.05
TD1000	0.16	0.04
Ti1000, TD1000, TD2000, and DOP1000	0.08	0.02
Ti2000, TD2000, TD4000, and DOP2000	0.04	0.01
Ti4000, TD4000, and DOP4000	0.02	0.005
Ti10KD and DOP10KD	0.008	0.002
Ti20KD and DOP20KD	0.004	0.001

##### Reference<sup>1</sup>



Synchronised pulse Z, duration as resolution.  
Bi-directionally repeatable.<sup>2</sup>

##### Wide reference<sup>1</sup>



Synchronised pulse Z, duration as resolution.  
Bi-directionally repeatable.<sup>2</sup>

#### NOTES:

- Select 'standard' or 'wide' reference at time of ordering, to match the requirements of the controller being used. See 'Ti interface part numbers' in the *TONiC™ encoder system* data sheet (Renishaw part no. L-9517-9337).
- The wide reference mark option is not available with Ti0004.


<sup>1</sup> For clarity, the inverse signals are not shown.

<sup>2</sup> Only the calibrated reference mark is bi-directionally repeatable.


## Limits

Open collector output, asynchronous pulse

### Active high



### or active low




### NOTES:

- There are no limits on TD interfaces.
- P limit becomes E+ for Ti interface options E, F, G and H.

## Alarm<sup>1</sup>

Line driven (asynchronous pulse)



Alarm asserted when:


- The signal amplitude is < 20% or > 135%
- The readhead speed is too high for reliable operation

**NOTE:** Inverse signal E+ only available for DOP digital outputs, and Ti options E, F, G and H.

### or 3-state alarm

Differentially transmitted signals forced open circuit for > 15 ms when alarm conditions valid.

## Set-up



The set-up signal voltage is proportional to the incremental signal amplitude.<sup>2</sup>

<sup>1</sup> For clarity, the inverse signals are not shown.


<sup>2</sup> The set-up signal as shown is not present during the calibration routine.

## Analogue output signals

### Ti analogue (Ti0000), DOP (analogue output only), and direct output from all readheads

#### Incremental

Two channels  $V_1$  and  $V_2$  differential sinusoids in quadrature (90° phase shifted).




<sup>1</sup> Only the calibrated reference mark is bi-directionally repeatable.


## Limits

Open collector output, asynchronous pulse


### Ti0000 interfaces (active high)



### Direct output from readhead (active low)



## Set-up <sup>1</sup>



Between 50% and 70% the signal level  $V_x$  is a duty cycle.

Time spent at 3.3 V increases with incremental signal level.

At > 70% the signal level  $V_x$  is nominal 3.3 V.

**NOTE:** For the DOP interface see '[Set-up](#)' in the digital outputs section on page [38](#).

---

## NOTES:

- The Ti0000 interface contains a transistor to invert the readhead's "active low" signal to give an "active high" output.
- For the DOP interface see '[Limits](#)' in the digital outputs section on page [38](#).

---

<sup>1</sup> The set-up signal as shown is not present during the calibration routine.

## General specifications

<b>Power supply</b>	5 V $\pm 10\%$	TONiC readhead only < 100 mA TONiC readhead with Ti0000 < 100 mA TONiC readhead with Ti digital interface or TD interface < 200 mA TONiC readhead with DOP interface < 275 mA Current consumption figures refer to unterminated systems. For digital outputs a further 25 mA per channel pair (eg A+, A-) will be drawn when terminated with 120R. For analogue outputs a further 20 mA in total will be drawn when terminated with 120R. Power from a 5 V dc supply complying with the requirements for PELV of standard IEC 60950-1. 200 mVpp maximum @ frequency up to 500 kHz
<b>Temperature</b>	Storage (system) Operating (system) Bakeout (UHV readhead)	-20 °C to +70 °C 0 °C to +70 °C +120 °C
<b>Humidity</b>	System	95% relative humidity (non-condensing) to IEC 60068-2-78
<b>Sealing</b>	Standard readhead UHV readhead Ti/TD interface DOP interface	IP40 IP20 IP20 IP30
<b>Acceleration</b>	Operating (readhead)	500 m/s <sup>2</sup> , 3 axes
<b>Shock</b>	Operating (system)	500 m/s <sup>2</sup> , 11 ms, ½ sine, 3 axes
<b>Vibration</b>	Operating (system)	Sinusoidal 100 m/s <sup>2</sup> , 55 Hz to 2000 Hz, 3 axes
<b>Mass</b>	Readhead Ti/TD interface DOP interface Standard cable UHV cable	10 g 100 g 205 g 26 g/m 14 g/m
<b>Readhead cable</b>	Standard readhead  UHV readhead	Double-shielded, outside diameter 4.25 $\pm 0.25$ mm Flex life > 20 $\times 10^6$ cycles at 20 mm bend radius UL recognised component  Tin coated braided single screen FEP core insulation
<b>Maximum cable length</b>	Readhead to interface Interface to controller	10 m 25 m (with 40 MHz to 50 MHz clocked output interface) 50 m (with < 40 MHz clocked output interface) 50 m (with analogue interface)

**CAUTION:** Renishaw encoder systems have been designed to the relevant EMC standards, but must be correctly integrated to achieve EMC compliance. In particular, attention to shielding arrangements is essential.

## RTLC20-S scale specifications

<b>Form (Height x Width)</b>	0.4 mm x 8 mm (including adhesive)
<b>Pitch</b>	20 µm
<b>Accuracy (at 20 °C)</b>	±5 µm/m (calibration traceable to International Standards)
<b>Linearity</b>	±2.5 µm/m (achievable with two point error correction)
<b>Supplied lengths<sup>1</sup></b>	20 mm up to 10 m (> 10 m on request)
<b>Material</b>	Hardened and tempered martensitic stainless steel fitted with a self-adhesive backing tape
<b>Mass</b>	12.9 g/m
<b>Coefficient of thermal expansion (at 20 °C)</b>	10.1 ±0.2 µm/m/°C
<b>Installation temperature</b>	+15 °C to + 35 °C
<b>Datum fixing</b>	Loctite® 435™ with A-9585-0028 datum clamp

## Reference mark

<b>Type</b>	Customer selected IN-TRAC reference mark, directly embedded into incremental track. Bi-directional position repeatability.
<b>Selection</b>	Single reference mark selection by selector magnet (A-9653-0143) customer positioned Single reference mark at scale centre Reference marks at 50 mm spacing (first reference mark 50 mm from scale end)
<b>Repeatability</b>	Unit of resolution repeatability (bi-directional) across full system rated speed and temperature ranges

## Limit switches

<b>Type</b>	Magnetic actuators; with dimple triggers Q limit, without dimple triggers P limit (see 'RTLC20-S scale installation drawing' on page 14)
<b>Trigger point</b>	The limit output is nominally asserted when the readhead limit switch sensor passes the limit magnet leading edge, but can trigger up to 3 mm before that edge
<b>Mounting</b>	Customer placed at desired locations
<b>Repeatability</b>	< 0.1 mm

<sup>1</sup> For lengths > 2 m FASTRACK with RTLC20 is recommended. Refer to the *TONiC™ T1x3x RTLC20/FASTRACK incremental linear encoder system* installation guide (Renishaw part no. M-9589-9002).

[www.renishaw.com/contact](http://www.renishaw.com/contact)

 [#renishaw](#)

 +44 (0) 1453 524524

 [uk@renishaw.com](mailto:uk@renishaw.com)

© 2010–2026 Renishaw plc. All rights reserved. This document may not be copied or reproduced in whole or in part, or transferred to any other media or language by any means, without the prior written permission of Renishaw.

RENISHAW® and the probe symbol are registered trade marks of Renishaw plc. Renishaw product names, designations and the mark 'apply innovation' are trade marks of Renishaw plc or its subsidiaries. Other brand, product or company names are trade marks of their respective owners. Renishaw plc. Registered in England and Wales. Company no: 1106260. Registered office: New Mills, Wotton-under-Edge, Glos, GL12 8JR, UK.

WHILE CONSIDERABLE EFFORT WAS MADE TO VERIFY THE ACCURACY OF THIS DOCUMENT AT PUBLICATION, ALL WARRANTIES, CONDITIONS, REPRESENTATIONS AND LIABILITY, HOWSOEVER ARISING, ARE EXCLUDED TO THE EXTENT PERMITTED BY LAW. RENISHAW RESERVES THE RIGHT TO MAKE CHANGES TO THIS DOCUMENT AND TO THE EQUIPMENT, AND/OR SOFTWARE AND THE SPECIFICATION DESCRIBED HEREIN WITHOUT OBLIGATION TO PROVIDE NOTICE OF SUCH CHANGES.

Part no.: M-9589-9013-04-A  
Issued: 01.2026