Issue 1 M-9539-2017-02-A



Interface bracket mounting



To mount the brackets to the ends of the interface:

- 1) Remove the locking posts
- 2) Discard the washers
- 3) Install the bracket as shown
- 4) Tighten locking posts to 0.35 Nm

The interface can then be installed with any suitable screws (M4 maximum thread size) that fit in the cut outs and do not interfere with the connector.