

Renishaw CNC Reporter

Renishaw CNC Reporter is a PC-based statistical analysis package designed to import, interrogate and analyse measurement and inspection data obtained using Renishaw machine tool probing software.

Providing a comparison of actual measured data against nominal values, the package uses colour coding to indicate adherence to tolerance and displays a Pass/Fail outcome at individual feature and component level. Results are provided in both graphical and tabular formats – simply select the view that best suits your quality control requirements.



Features and benefits

- · Highly visual data display in an easy to understand, configurable, Microsoft Excel format
- Colour-coded reports provide an instant Go/No-go decision
- · Feature tracking and capability charts to monitor process variation over time
- · Import data from up to 400 components into the same file
- · Data Manager application for analysis of large volumes of historical data
- · Export data to external statistical process control (SPC) and other packages for additional analysis
- Customisable report templates

Renishaw software solutions for machine tools

Renishaw's Productive Process Pyramid[™] provides a framework within which to identify and control variation in manufacturing. This framework, backed by innovative technology, proven methods of incorporating process and an extensive, expert support network, mean Renishaw can make your goal of 'green button' or 'lights out' manufacturing a reality.

The range of workpiece measurement and inspection software packages available from Renishaw provide solutions across all layers of the Productive Process Pyramid from integrated probe qualification, through to tool setting, adaptive machining and reporting.



The Productive Process Pyramid™

Renishaw CNC Reporter

Renishaw CNC Reporter, positioned within the post-process monitoring layer of the Pyramid, is a dedicated application for the review and analysis of measurement inspection data obtained using Renishaw machine tool probing software.

The application provides a quick and simple means of displaying actual measurement data against feature tolerance and indicating conformance to tolerance. Review of part deviation over time is also possible, helping to determine machine capability and to schedule preventative maintenance tasks.



CNC machine tool





Renishaw CNC Reporter





Using Renishaw CNC Reporter

Import data

Two methods of data import are available: 'Collect Data – File Import' and 'Collect Data – Real Time'*. The File Import method imports existing measurement and inspection data from a defined file location, importing all available data in a single step. The Real Time method of data collection periodically accesses a file location to extract newly added measurement data.

Once imported, data is displayed in a series of Probing Inspection Reports – one report for each inspected component.

These reports provide the first opportunity to review component inspection data, displaying nominal dimensions, actual measured data, deviation from nominal and tolerance values, plus a pass/fail indication for each measured feature and overall component.

Click to Collect Data automatically Collect Data - REAL TIME Data Retrieval Method TEXT	Lock Senap						
Ick to Collect Data from a stored Text Collect Data - FILE IMPORT	File						
Click to Create Capability Chart Compile Capability Chart	J						
ck to remove all existing inspection Si Clear Data	hoets						
Sck to create a Saved file without mac Create Archive	ros					apply innovation	AV
Activate Quality Warnings							
Specified Limits Warning Limit	ts						
E 1.		Part Number:		4001	Name:	Na	me
Warning Limits Multiplier (%)		Operation:		1	Sample ID:	Sam	ple 1
76.0%		Machine Type:	Demo	Machine	Date:	18/05	/201
Redisplay Quality Warnings		Work Centre ID:	1	lemo	Units:	Me	tric
		Actual	Deviation	Lower Tolerance	Upper Tolerance	in Tolerance?	
Contraction of the second seco							
A001	1	ONC_1					-
ADDI	1	ONC_1					
ADDI	0.0000	0.0500	0.0500	4.1000	0.1000	YES	
ADDI 01 2 TOP SUMP TO1 POSITION 2 WORK OFFSET UPDATED	0.0000	0.0500	0.0500	-0.1000	0.1000	YES	
ADDS DI Z TOP SUBFTOL POSITION Z WORK OFFSET UPDATED	0.0000	0.0500	0.0500	-0.1000	0.1000	783	
ADDI DI I TOP SUBJ TOI POSTION Z WORK OFFSET UPDATED D2 BORE 40 SOMM TE2	0.0000	0.0500	0.0500	-0.1000	0.1000	YES	
A005 D1 2 TOP SUBFTO1 POSITION Z WORK OFFSET UPDATED D2 BORE 40 80484 T82 5/22	1 0.0000 554 40.0000	0.0500 40.0100	0.0500	-0.1000	0.1000	YES YES	
AGE 12 TOP SUM TOL POSITION 2 WORK OFNET UPDATED 02 SORE 4 SORMATES SIZE POSITION X	1 0.0000 554 40.0000 12.5000	CNC_1 0.0500 41.0100 12.5100	0.0500 0.0106 0.0106	-0.1000 -0.1000 -0.000	0.1000	YES YES YES	
ADDE	1 0.0000 554 40.0000 12.5000 -10.0000	CNC_1 0.0500 40.0100 12.5100 -30.0300	0.0500 0.0100 0.0100 -0.0500	-0.1000 -0.1000 -0.0000 -0.0000 -0.0000	0.1000	YE5 YE5 YE5 YE5	
Additional	1 0.0000 551 40.0000 12.5000 -10.0000 0.0000	015_1 0.0500 40.0100 12.5100 -0.0500 -0.0500	0.0000 0.0106 0.0100 -0.0300 -0.0300	-0.1000 -0.1000 -0.0500 -0.0500 -0.1000	0.1000 0.1000 0.0500 0.0500 0.1000	YES YES YES YES	
Addition 51 2 TOP SUM TOS 52 2 TOP SUM TOS 50 TOP 2 WORK OFFECT OPARTED OF SORE 4025MA TED 50 E 50 F 50 F	1 0.0000 551 40.0000 12.5000 -10.0000 0.0000	0K_1 0.0000 40.0100 12.5100 -0.0300 -0.0300	0.0000 0.0000 0.0000 -0.0000 -0.0000	-0.1000 -0.1000 -0.000 -0.1000 -0.1000	0.1000 0.1000 0.0500 0.0500 0.1000	YES YES YES YES	
AND	1 0.0000 554 40.0000 12.5000 -10.0000 0.0000 23.2000	015_1 0.0500 40.0100 12.5100 -08.0500 4.0500 23.2300	0.0500 0.0300 -0.0300 -0.0300 -0.0300	-0.1000 -0.1000 -0.000 -0.1000 -0.1000	0.1000 0.1000 0.0500 0.1000 0.1000	YES YES YES YES YES	
Acce SLI TOP SIMPTSI POSTORY I POSTORY I	1 0.0000 354 40.0000 12.5000 0.0000 0.0000 0.0000 25.0000	0K_1 0.0500 40.0100 12.5100 48.0500 48.0500 23.2500 23.8909	0.0500 0.0500 0.0500 -0.0500 -0.0500 0.0500	-4.1000 -4.1000 -4.0000 -4.0000 -4.1000	0.1000	YES YES YES YES YES	
AND	1 0.0000 355 40.0000 12.35000 -10.0000 0.0000 23.2000 0.0000	0K_1 0.0500 41.0100 12.5100 -98.0500 4.0500 25.2500 22.5000 22.5000 4.0500	0.0500 0.0100 0.0100 -0.0500 -0.0500 0.0100 -0.1091 -0.000	41000 41000 40500 41000 41000 41000	0.1000	YES YES YES YES YES NO	
All TOP RAY TSL SLIT OF RAY TSL SUBJECTION I WORK CHIEFT UNALTED ST SOFT A STATUS ST SOFT AS ASSAMMENTE ST ST ST ST ST ST ST ST ST ST	1 0.0000 551 40.0000 0.0000 0.0000 25.2000 25.2000 25.0000 0.0000	01(_1 0100) 40,0100 12,5100 40,0100 40,0100 21,2100 21,2100 21,2100 21,2100 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010 40,010	0.0000 0.0100 0.0100 -0.0500 -0.0500 -0.1000 -0.1001 -0.0000	41000 41000 40500 40500 41000 40500 40500	0.1000 0.1000 0.0000 0.0000 0.0000 0.0000 0.0000	YES YES YES YES NO	
13.1 TOP Rev TSL 15.1 TOP Rev TSL 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 9000001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 900001 90001 <td>1 0.0000 555 40.0000 0.0000 0.0000 25.000 25.000 0.0000</td> <td>0K_1 2.8900 46.9500 45.9500 45.9500 23.2800 24.8001 4.9600</td> <td>0.0500 0.0500 -0.0500 -0.0500 -0.0500 -0.0500 -0.0500</td> <td>41000 41000 40500 40500 41000 40500 40500</td> <td>0.1000 0.5000 0.6500 0.6500 0.6500 0.6500 0.6500</td> <td>YES YES YES YES YES NO</td> <td></td>	1 0.0000 555 40.0000 0.0000 0.0000 25.000 25.000 0.0000	0K_1 2.8900 46.9500 45.9500 45.9500 23.2800 24.8001 4.9600	0.0500 0.0500 -0.0500 -0.0500 -0.0500 -0.0500 -0.0500	41000 41000 40500 40500 41000 40500 40500	0.1000 0.5000 0.6500 0.6500 0.6500 0.6500 0.6500	YES YES YES YES YES NO	
Aless St Tree Ray Yst. Address Yst. Address Yst. Set Source Assessed To Set Source Set Source Assessed To Set Set Source Set Source Assessed To Set Set Source Set Source Assessed To Set Set Source Set Source Assessed To Set Source Set Source Assessed T	1 0.6000 551 40.0000 12.5000 -10.0000 0.6000 23.2000 23.2000 23.0000 0.6000	016_1	0.0500 0.0500 -0.0500 -0.0500 -0.0500 -0.0500 -0.0500 -0.0500	4 1000 4 1000 4 0000 4 0000 4 0000 4 0000	0.1000 0.1000 0.8500 0.1000 0.8500 0.8500 0.8500	YES YES YES YES YES NO	
Less Es Transar Yas dans control (Santa) allan control (Santa) allan control (Santa) Santa Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa) Santa	1 0.0000 551 12.5000 -10.0000 0.0000 23.2000 23.2000 0.0000 0.0000	0K_1 2.8500 41.8100 11.5100 48.8100 4.8000 21.2300 21.2300 21.8000 4.8000 4.8000	0.6500 0.6500 -0.6500 -0.6500 -0.6500 0.6500 -0.1591 -0.2595	-8.1000 -0.000 -0.000 -0.000 -0.000 -0.000 -0.000	0.1000 0.500 0.5500 0.5500 0.5500 0.5500 0.5500 0.5500	785 785 785 785 785 785 785	
AMB Internet Wisk Station 1 Station 1 Station 2 Station 1 Station 2 Station 1 Station 2 Station 1 Station 2 Station 2	1 0.0000 554 40.0000 125.500 0.0000 0.0000 25.0000 0.0000	016_1	6.0500 6.0100 0.0100 -0.0500 -0.0500 -0.0500 -0.1091 -0.0600	-0.1000 -0.1000 -0.000 -0.1000 -0.000 -0.000 -0.000	0.1000 0.1000 0.0000 0.0000 0.0000 0.0000 0.0000	715 715 715 715 715 715 NO	
ABS Ist Top Karly TSL Addition 21 addition 21 addition 20 Addition 20 Additio	1 0.0000 554 40.0000 12.5000 0.0000 23.5000 23.5000 0.0000	016_1	0.0508 0.0509 0.0505 0.0500 0.0500 0.0509 0.0509 0.0509	4.1000 4.5500 4.5500 4.5500 4.5500 4.5500	0 1000 0 1000 0 8500 0 8500 0 8500 0 8500 0 8500	985 985 985 985 985 985 985 985 985 985	

* Due to the differences in machine configuration and data transfer methods, please contact your local Renishaw representative when considering use of the real time data import method in conjunction with Renishaw CNC Reporter.



Review and analyse

Results information can also be viewed graphically via the Capability Chart. This displays the variation of measured values for a single feature across all inspected components, along with tolerance and warning limits. Statistical data – such as mean, range and standard deviation – is also displayed. Filters allow the range of displayed data to be refined, adjusting the feature for which data is displayed, or reducing the number of components in the sample. Statistical data is automatically updated as these filters are applied.

A further visual indication of results is available via the Overview tab. This provides a Red Amber Green (RAG) chart of size and position data along with a range of statistical data. Colour coding of the cells – based on warning and tolerance limits – indicate features which are in tolerance, approaching tolerance and out of tolerance. Again, filters allow displayed data to be refined and statistical data is automatically updated accordingly.



Archive data

Once initially processed, results data can be saved as a workbook archive. This data can then be analysed further using Data Manager, an additional application which automatically installs alongside Renishaw CNC Reporter.

Data selections are made based on the component part number, the CNC machine tool used to capture the original results data, and the date range over which that data was collected.

Display options include Archive Query – the default, tabular display and that used to select and import archive data; an Overview (RAG chart) – using colour-coded cells to indicate adherence to tolerance; and a Comparison Chart – providing graphical representation of measured data for multiple features across multiple components.

Displayed data can be refined and adjusted using filters and 'feature slicers'.

About Select Machine: Demo Probing Report Select Part Number: Of Machine: Select Part Number: Of Machine: ADDI Of Machine: Select Part Number: Of Machine: Month Of Machine: Iter by Feature Select Part Number:

Customise

When dealing with large volumes of results data, custom templates can be created and used to visually differentiate the automatically generated Probing Inspection Reports. Simply add a component image, drawing or corporate logo to the Probing Inspection Report template.

Renishaw CNC Reporter can then be configured to select and use a specific template for all results data imported from a single file, or to vary the template used dependent on the inspected component.



New Mills, Wotton-under-Edge Gloucestershire, GL12 8JR United Kingdom

T +44 (0) 1453 524524 F +44 (0) 1453 524901 E uk@renishaw.com www.renishaw.com



Renishaw CNC Reporter

Part number

The part number of the software is A-4007-1500. Please quote this part number when ordering.

Supported languages

Renishaw CNC Reporter is available in English only.

Compatibility

Data collection software

Renishaw CNC Reporter is capable of processing measurement and inspection data gathered using applications from the PC-based Productivity+™ software suite (Productivity+™ Active Editor Pro, Productivity™+ GibbsCAM plug-in, Productivity+™ CNC plug-in, and third party software applications incorporating the Productivity+™ API) and the machine resident, macro-based Inspection Plus* package.

* Configuration by Renishaw applications engineers is required before Inspection Plus data can be used in conjunction with Renishaw CNC Reporter.

NOTE: Some CNC machine tool controller platforms which are compatible with these software applications do not support the output of inspection report data and are therefore not compatible with Renishaw CNC Reporter. For further information, or to confirm compatibility of your CNC machine tool control, please contact your local Renishaw representative.

Supported controllers

Measurement and inspection data from most CNC machine tool controllers* that support probing can be processed by Renishaw CNC Reporter, including:

Fanuc

 Haas Heidenhain

- Hitachi Seicos
- Mitsubishi

Okuma

• Siemens

Makino

Mazak

- Mori Seiki
- Yasnac

* Supported controller type is dependent on the data collection software used to gather the measurement and inspection data.

Renishaw CNC Reporter is intended for use with a single CNC machine tool. If there is a requirement to simultaneously import data from multiple machine tools, the equivalent number of seats of Renishaw CNC Reporter are required.

PC specification

Operating system	Microsoft Windows 7 (or later)			
Processor	2.0 GHz Intel Core 2 Duo (or equivalent)			
Memory	4 GB RAM, 1 GB hard disk space			
Other	CD/DVD drive for software installation			
	Microsoft Excel 2007 (or later): Microsoft Excel 2016 recommended			

Multiple instances of Renishaw CNC Reporter (a recommended maximum of four) can be run concurrently and displayed on a single screen.

For worldwide contact details, visit www.renishaw.com/contact

RENISHAW HAS MADE CONSIDERABLE EFFORTS TO ENSURE THE CONTENT OF THIS DOCUMENT IS CORRECT AT THE DATE OF PUBLICATION BUT MAKES NO WARRANTIES OR REPRESENTATIONS REGARDING THE CONTENT. RENISHAW EXCLUDES LIABILITY, HOWSOEVER ARISING, FOR ANY INACCURACIES IN THIS DOCUMENT.

© 2014–2017 Renishaw plc. All rights reserved. Renishaw reserves the right to change specifications without notice. **RENISHAW** and the probe symbol used in the RENISHAW logo are registered trade marks of Renishaw plc in the United Kingdom and other countries. **apply innovation** and names and designations of other Renishaw products and technologies are trade marks of Renishaw plc or its subsidiaries. All other brand names and product names used in this document are trade names, trade marks or registered trade marks of their respective owners.



Part no.: H-5464-8200-03-A Issued: 03.2017