

ADT View software release notes (Version 4.2.1.0)

Release date: February 2026

Changes:

- Fixed an issue where copying hyperlinks from the information screen could cause ADT View to freeze.
- Fixed an issue where setting zero on supported absolute readheads could cause crashes or unexpected results when using languages that have commas as their decimal separator.
- Minor bug fixes.

Known issues in this release:

- Potential graphical bug on rotary signal vs position plot, if setting trigger to “0 on Z” while already above a reference mark.
- If ADTpro-100 with TONiC/ATOM is connected to ADT View while already in calibration mode, ADT View will not display the calibration guide until re-requested.
- When the language is changed, some translations do not update until the software is restarted.

www.renishaw.com/adt

 #renishaw

 +44 (0) 1453 524524  uk@renishaw.com

© 2021–2026 Renishaw plc. All rights reserved. This document may not be copied or reproduced in whole or in part, or transferred to any other media or language by any means, without the prior written permission of Renishaw.
RENISHAW® and the probe symbol are registered trade marks of Renishaw plc. Renishaw product names, designations and the mark 'apply innovation' are trade marks of Renishaw plc or its subsidiaries. Other brand, product or company names are trade marks of their respective owners.

WHILE CONSIDERABLE EFFORT WAS MADE TO VERIFY THE ACCURACY OF THIS DOCUMENT AT PUBLICATION, ALL WARRANTIES, CONDITIONS, REPRESENTATIONS AND LIABILITY, HOWSOEVER ARISING, ARE EXCLUDED TO THE EXTENT PERMITTED BY LAW. RENISHAW RESERVES THE RIGHT TO MAKE CHANGES TO THIS DOCUMENT AND TO THE EQUIPMENT, AND/OR SOFTWARE AND THE SPECIFICATION DESCRIBED HEREIN WITHOUT OBLIGATION TO PROVIDE NOTICE OF SUCH CHANGES.

Renishaw plc. Registered in England and Wales. Company no: 1106260. Registered office: New Mills, Wotton-under-Edge, Glos, GL12 8JR, UK.

Part no.: L-9517-9890-04-D

Issued: 02.2026