


# RELM high accuracy incremental linear ZeroMet™ scale



**RELM20 ZeroMet™ scale is manufactured from near zero thermal expansion material, ensuring the high level of accuracy is maintained across the full temperature range.**

It can be mounted direct to your machine, either mechanically or by the use of a self-adhesive backing tape. RELM20 scale also features the *IN-TRAC*™ optical reference mark allowing fast auto-phasing.

RELM20 is a 20 µm pitch scale and is compatible with Renishaw's VIONiC™ and TONiC™ range of encoders, offering levels of performance previously only available from delicate fine pitch systems.

- Robust ZeroMet™ offers  $0.75 \pm 0.35 \mu\text{m}/\text{m}/^\circ\text{C}$  (at 20 °C) thermal expansion plus ease of handling and installation
- $\pm 1 \mu\text{m}$  guaranteed accuracy up to 1 metre
- Scale mounting options: self-adhesive or clips and clamps
- Available in lengths up to 1.7 m
- *IN-TRAC* bi-directional auto-phase optical reference mark
- Dual limits provide on-scale end of travel indication
- Compatible with VIONiC and TONiC incremental readheads

## RELM scale specifications

<b>Description</b>	High stability, low-expansion nickel-iron alloy ZeroMet spar scale for use with VIONiC and TONiC readheads
<b>Pitch</b>	20 µm
<b>Form (height x width)</b>	1.6 mm x 14.9 mm (excluding adhesive)
<b>Accuracy (at 20 °C)</b>	Certified to ±1 µm up to 1 m, ±1 µm/m for lengths > 1 m. Calibration traceable to International Standards
<b>Coefficient of thermal expansion (at 20 °C)</b>	0.75 ±0.35 µm/m/°C
<b>Mass</b>	184 g/m
<b>Available lengths</b>	20 mm to 1.7 m (available in increments of 10 mm)
<b>Measuring length</b>	See 'RELM20 scale measuring length' on page 8
<b>Mounting</b>	Epoxy datum point and adhesive tape or mechanical datum clamp and mounting clips.

For further information on installation and mounting options, refer to the following documentation:

Encoder system	Document name	Document part number	Website link
VIONiC	VIONiC™ RSLM20/RELM20 high-accuracy incremental linear encoder system installation guide	M-6195-9232	<a href="http://www.renishaw.com/vionicdownloads">www.renishaw.com/vionicdownloads</a>
TONiC	TONiC™ RSLM20/RELM20 high-accuracy incremental linear encoder system installation guide	M-9653-9225	<a href="http://www.renishaw.com/tonicdownloads">www.renishaw.com/tonicdownloads</a>


## Reference mark

<b>Type</b>	<i>IN-TRAC</i> ™ autophase optical reference mark; no physical adjustment required	
<b>Position</b>	RELM20 <sup>1</sup>	Midpoint of the scale length
	RELE20 <sup>1</sup>	20 mm from the end of the scale length
<b>Phasing</b>	Auto-phased by readhead calibration routine	
<b>Repeatability</b>	Repeatable to unit of resolution throughout the specified temperature and speed range	

## Limit switches

<b>Type</b>	Magnetic actuators; with dimple triggers Q limit, without dimple triggers P limit (see image below)	
<b>Trigger point</b>	The limit output is nominally asserted when the readhead limit switch sensor passes the limit magnet leading edge, but can trigger up to 3 mm before that edge	
<b>Mounting</b>	Customer placed at desired locations	
<b>Repeatability</b>	< 0.1 mm	



**NOTE:** Limit magnets are available in 10 mm (standard), 20 mm, 25 mm, and 50 mm lengths and provided on a back plate with self-adhesive tape.



<sup>1</sup> VIONiC and TONiC readheads should be ordered with all reference marks output (No reference mark selector is required.)

<sup>2</sup> The limit magnet locations are correct for the readhead orientation shown.

## Compatible readheads

	VIONiC	TONiC
		
<b>Outputs</b>	Digital resolutions from 5 µm to 2.5 nm direct from the readhead	Analogue 1 Vpp. Digital resolutions from 5 µm to 1 nm when connected to a Ti, TD or DOP interface.
<b>Sub-divisional error (typical)</b>	< ±15 nm	±30 nm
<b>Jitter (RMS)</b>	Down to 1.6 nm	Down to 0.5 nm
<b>Maximum speed</b>	12 m/s	10 m/s
<b>UHV variant</b>	No	Yes <sup>1</sup>
<b>Functional Safety variant</b>	No	Yes <sup>2</sup>

## Readhead features




- Filtering optics and Auto Gain Control for high reliability and solid Lissajous signals.
- Dynamic signal processing ensures ultra-low sub-divisional error (SDE). Result: smoother scanning performance.
- High signal-to-noise ratio provides ultra-low jitter for optimum positional stability.
- Auto-phasing of *IN-TRAC* reference mark.
- Clocked outputs ensure optimised speed performance for all resolutions, for a wide variety of industry-standard controllers.
- DOP Dual output interfaces available to provide simultaneous analogue and digital outputs (TONiC systems only).

<sup>1</sup> See *TONiC™ UHV encoder system* data sheet (Renishaw part no. L-9517-9426) for further details.

<sup>2</sup> See *TONiC™ Functional Safety incremental encoder system* data sheet (Renishaw part no. L-9517-9878) for further details.

# RELM scale installation drawing - adhesive mounted

Dimensions and tolerances in mm





**NOTE:** Adhesive mounted scale should not be reused after installation.

- <sup>1</sup> When the scale is to be mounted vertically, position the dowels so that the datum edge is supported.
- <sup>2</sup> Epoxied area, usually coincident with IN-TRAC reference mark (RELE20 shown).

# RELM scale installation drawing - clip/clamp mounted

Dimensions and tolerances in mm




**NOTE:** For further details on clip/clamp mounting REL\* scale see the notes on page 7.

## Clip/clamp mounting

Dimensions and tolerances in mm

### Mounting clip/Datum clamp




---

#### NOTES:

- The datum clamp is usually coincident with the selected *IN-TRAC* reference mark. However, the position is user selectable depending upon application.
  - For lengths  $80 \leq L \leq 190$  ensure that the scale is clamped or clipped in the middle as well as at both ends.
    - The installation should use the least number of clips as possible.
    - For lengths not specified, contact your local Renishaw representative for further advice.
  - For optimum performance the readhead should be installed close to nominal geometry.
  - Care should be taken to ensure sufficient clearance between the readhead/mounting bracket and clips/datum clamp.
  - Only special low-profile screws should be used. Screws are provided with all clips/datum clamps, and spares can be supplied if required.
-

# RELM20 scale measuring length

Dimensions and tolerances in mm








## Scale part numbers

### 20 µm pitch ZeroMet spar scale




Series	Reference mark	Available lengths	Available in increments of	Part number (where xxxx is the length in mm) <sup>1</sup>
RELM20	Single <i>IN-TRAC</i> reference mark at mid-point of scale length	20 mm to 1700 mm	10 mm	A-9660-xxxx
RELE20	Single <i>IN-TRAC</i> reference mark 20 mm from scale end	30 mm to 1700 mm	10 mm	A-9661-xxxx

## Accessory part numbers

### Limit magnets <sup>2</sup>

Part description	Part number	Product image
10 mm long Q limit switch actuator magnet (Adhesive mounted)	A-9653-0139	
10 mm long P limit switch actuator magnet (Adhesive mounted)	A-9653-0138	
Magnet applicator device (Aids positioning)	A-9653-0201	





### Self-adhesive mounting accessories

Part description	Part number	Product image
Adhesive backing tape (5 m) (nominal thickness 0.2 mm)	A-9584-2111	
Adhesive backing tape applicator Aids the application of the adhesive backing tape to the scale	A-9584-0601	
RGG-2 two part epoxy adhesive Used to create a datum point	A-9531-0342	

<sup>1</sup> Ordering A-9660-0070, for example, will result in a length of 70 mm of RELM20.


<sup>2</sup> Longer limit magnets are available. Contact your local Renishaw representative for more information.

**Clip/clamp mounting accessories**

Part description	Part number	Product image
<p><b>Mounting clips</b> <sup>1</sup></p>	<p>A-9584-2049</p>	
<p><b>Datum clamp kit</b> <sup>1</sup></p>	<p>A-9584-2050</p>	
<p><b>Replacement M3 screws</b> (pack of 25)</p>	<p>A-9584-2047</p>	
<p><b>Spare clip setting shim</b></p>	<p>M-9584-0928</p>	

<sup>1</sup> UHV and extra wide clip/clamp accessories are available. Contact your local Renishaw subsidiary for more information.

## Compatible products



[www.renishaw.com/contact](http://www.renishaw.com/contact)



#renishaw

+44 (0) 1453 524524

 [uk@renishaw.com](mailto:uk@renishaw.com)

© 2006–2025 Renishaw plc. All rights reserved. This document may not be copied or reproduced in whole or in part, or transferred to any other media or language by any means, without the prior written permission of Renishaw.

RENISHAW® and the probe symbol are registered trade marks of Renishaw plc. Renishaw product names, designations and the mark 'apply innovation' are trade marks of Renishaw plc or its subsidiaries. Other brand, product or company names are trade marks of their respective owners.

WHILE CONSIDERABLE EFFORT WAS MADE TO VERIFY THE ACCURACY OF THIS DOCUMENT AT PUBLICATION, ALL WARRANTIES, CONDITIONS, REPRESENTATIONS AND LIABILITY, HOWSOEVER ARISING, ARE EXCLUDED TO THE EXTENT PERMITTED BY LAW. RENISHAW RESERVES THE RIGHT TO MAKE CHANGES TO THIS DOCUMENT AND TO THE EQUIPMENT, AND/OR SOFTWARE AND THE SPECIFICATION DESCRIBED HEREIN WITHOUT OBLIGATION TO PROVIDE NOTICE OF SUCH CHANGES.

Renishaw plc. Registered in England and Wales. Company no: 1106260. Registered office: New Mills, Wotton-under-Edge, Glos, GL12 8JR, UK.

Part no.: L-9517-9219-08-A

Issued: 01.2025