



[New](#) [Closed](#) [Wish](#) [Info](#) [Admin](#) [ViewAll](#) [Search :](#)

		102 : Demo: Should \$MSRDefaultFile be cancelled in IO_GetMSR	14/04/2010
JSC		101 : Need a way to signal MSPPRC to continue	16/04/2010
JSC		100 : Siemens840D: Need to implement the hole offsets macro MSPHOF	23/04/2010
CLH		99 : Need to be able to Invalidate an MSPROT / Alignment	16/04/2010
LTM		92 : Need to be able to configure multiple machines in one NC-Connector	27/04/2010
LTM		91 : We need to convert the ATEKs into proper installs	27/04/2010
3.01.10	PB	90 : Crash when dealing with long (259+ chars) strings in the command window	15/10/2009
		86 : Siemens needs ability to output a tapefile	08/10/2009
		85 : Mazak probe calibration automation	29/09/2009
		84 : Mazak needs 5 axis support	23/07/2009
		78 : We have no ncconnector for the fanuc	22/02/2010
JSC		73 : Siemens 840D needs to be completed	16/04/2010
		67 : Bouncing ball could be shown by serial port pages	08/10/2009
		64 : Mazatrol Matrix: Load/Unload programs	01/10/2009

14 items outstanding

with 1 scheduled items